SCH-i600 Series

Portable Digital Dual Band Telephone

User Guide

Please read this guide before operating your phone, and keep it for future reference.

Intellectual Property

All Intellectual Property, as defined below, owned by or which is otherwise the property of Samsung or its respective suppliers relating to the SAMSUNG Phone, including but not limited to, accessories, parts, or software relating thereto (the “Phone System”), is proprietary to Samsung and protected under federal laws, state laws, and international treaty provisions. Intellectual Property includes, but is not limited to, inventions (patentable or unpatentable), patents, trade secrets, copyrights, software, computer programs, and related documentation and other works of authorship. You may not infringe or otherwise violate the rights secured by the Intellectual Property. Moreover, you agree that you will not (and will not attempt to) modify, prepare derivative works of, reverse engineer, decompile, disassemble, or otherwise attempt to create source code from the software. No title to or ownership in the Intellectual Property is transferred to you. All applicable rights of the Intellectual Property shall remain with SAMSUNG and its suppliers.

Samsung Telecommunications America (STA), Inc.

Headquarters	**Customer Care Center**
1130 E. Arapaho Road	1601 E. Plano Parkway, Suite 150
Richardson, TX 75081	Plano, TX 75074
Tel: 972.761.7000	Toll Free Tel: 1.888.987.HELP (4357)
Fax: 972.761.7001	Fax: 972.761.7001 and 972.761.7501

Internet Address: http://www.samsungusa.com

Verizon Customer Care

verizonwireless.com is open 24 hours a day for customer service, general information, even shopping. But just in case, be sure to keep the following numbers handy.

Customer Service (6am–11pm): *611 SEND

24-Hour Technical Support (24 hrs.): *611 SEND

©2003 Samsung Telecommunications America, Inc. All rights reserved. No reproduction in whole or in part allowed without prior written approval. Samsung is a registered trademark of Samsung Electronics America, Inc. and its related entities.

Printed in South Korea, GH46-00050A
Openwave® is a registered Trademark of Openwave, Inc.
RSA® is a registered Trademark RSA Security, Inc.

T9 text input software Copyright © 1999 - 2003. Tegic Communications Corporation. All rights reserved.

Microsoft, ActiveSync, MSN, Outlook, Windows, the Windows logo, and Windows Media are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Disclaimer of Warranties; Exclusion of Liability

EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED ON THE WARRANTY PAGE ENCLOSED WITH THE PRODUCT, THE PURCHASER TAKES THE PRODUCT "AS IS", AND SAMSUNG MAKES NO EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE; THE DESIGN, CONDITION OR QUALITY OF THE PRODUCT; THE PERFORMANCE OF THE PRODUCT; THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO. NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE OR USE OF THE PRODUCT OR ARISING FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS.

Contents

Introduction 1
SCH-i600 features 1
SCH-i600 closed view 2
SCH-i600 open view 3
Battery and accessories 4
- Low battery indicator 4
- Install the battery 4
- Remove the battery 5
- Charge the battery 5

Getting Started 6
- Antenna 6
- Turn your Smartphone on 6
- The SCH-i600 display 6
- The Home Screen 6
- Display screen 7
- Icons 8
- Your Smartphone's keypad 9
- Hot keys 10
- Set up Voicemail 13
- Contact Customer Care 13

Make and answer calls 14
- Make a call from your Contacts list 14
- Answer Calls 15
- Use the speakerphone in a call 15

Navigate menus 16
- Navigate using shortcuts 16

Optional SD Card 17
- Transfer data to the SD Card from your computer 17
- Use the SD Card 19

Settings 20
- Call Options 20
- Sounds 21
- Profiles 22
- Home Screen 24
- About 25
- Accessibility 26

Data Connections 27
Date and Time 28
Owner Information 29
Power Management 30
Regional Settings 31
Remove Programs 32
Security 33
Phone Settings 34
TTY/TDD 35
Your Personal Digital Assistant 36
Calendar 36
Contacts 38
Program Speed Dial numbers 42
Microsoft® ActiveSync® 44
Minimum PC requirements 44
Install ActiveSync 45
Upload and access media files 47
Use ActiveSync via IR 49
Partnerships 58
Create a New Partnership 58
Text, symbols, and numbers 59
Enter text using T9 59
Enter text using Multi-tap 61
Enter numbers 62
Messaging 63
Voicemail 63
SMS Text Messages 63
E-mail 66
Voice Signal 72
Voice Signal Features 72
Understanding Roaming 77
Roaming 77
Roaming Options 77
Call History 78
View your Call History 78
Caller ID 82
Call Waiting 82
Three-way Calling 83
Tasks 84

Create a new task 84
Mark a Task complete 84
Activate a completed task 85
Delete a Task 85
Voice Notes 86
Make a recording 86
Rename a recording 87
Other Applications 88
Pocket Internet Explorer 88
MSN Messenger 90
My Text 95
Windows® MediaTM Player 8 for Smartphone 96
Solitaire 98
The Accessories menu 99
Calculator 99
Wireless Link 100
Infrared Receive 100
Modem link 102
Portable Keyboard (optional accessory) 104
Warranty 114
STANDARD LIMITED WARRANTY 114
Index 121

Introduction

Congratulations on your purchase of the Samsung SCH-i600. The SCH-i600 is a Windows Mobile™ based device and is compatible with Windows Mobile™ Smartphone applications. The SCH-i600 is an integrated communication device that allows you to make calls, send and receive e-mail, instant message friends and family, sync personal information with your PC, and much more. We ask that you take time to read this guide and become familiar with this phone's many features.

SCH-i600 features

- Large 170 x 220 pixel, 65k color Transflective TFT screen
- Pocket Outlook®
- High speed data (CDMA 2000 1X Technology)
- E911 Capable
- Windows Mobile™ software for Smartphones
- Short Message Service (SMS) Messaging
- Advanced Voice Recognition
- Pocket Internet Explorer
- Secure Digital (SD) Expansion Card Capability (Supports SDIO cards)
- Wave file, MIDI (Type 0) ring tone support
- Windows® Media Player™ 8 for Smartphone
- MSN Messenger
- ActiveSync®

SCH-i600 closed view

SCH-i600 open view

Battery and accessories

The SCH-i600 comes with a standard rechargeable battery, power accessory, and headset.

The battery for the SCH-i600 can be charged before it is fully drained without causing damage.

Low battery indicator

An audible alert sounds in standby and talk modes to alert you of a low battery.

- **In standby mode** with one bar left on the battery strength indicator ( ), the Smartphone beeps every five minutes until it shuts down (approximately 40 minutes for a standard battery; 100 minutes for an extended battery).
- **In talk mode** with one bar left on the battery strength indicator ( ), the Smartphone beeps every minute until it shuts down (approximately 10 minutes for a standard battery; 13 minutes for an extended battery).

Long backlight settings, searching for service, vibrate mode, browser use, and other functions affect talk/standby times.

Install the battery

1. Position the battery on back of the Smartphone so the plastic tabs on the battery line up with the grooves on the Smartphone.
2. Gently slide the battery toward the top of the Smartphone until it snaps into place.

a. b. c.



Remove the battery



1. Press the battery release latch and slide the battery toward the bottom end of the Smartphone.
2. Lift the battery to remove.

Charge the battery

Connect the Power Accessory

The power accessory allows you to charge your Smartphone's battery from any standard 120 VAC wall outlet. You can also place calls while the battery is charging.

1. With the battery installed, plug the connector from the power accessory into the Power/Interface connector at the bottom end of the Smartphone.
2. Plug the AC module for the power accessory into a standard 120 VAC wall outlet. Your Smartphone begins charging.

Although you can place calls while charging, the battery charges faster when the Smartphone is turned off.

Disconnect the Power Accessory

Once your battery is fully charged, disconnect the power accessory from the Smartphone.

1. Press the release button on top of the power accessory connector that is plugged into the Smartphone.
2. Pull the connector away from the Smartphone.
3. Disconnect the AC module from the 120 VAC wall outlet.

Getting Started

Antenna

Avoid touching the antenna while the phone on. Contact with the antenna affects the quality of your calls and may cause the phone to operate at a higher power level than necessary.

Turn your Smartphone on

Once you've installed and fully charged the battery, press and hold END/PWR. Your service provider's name and logo briefly appear in the display, followed by the Home Screen.

The SCH-i600 display

There are two different types of screen displays for your Smartphone, the **Home Screen** and the **Display Screen**.

The Home Screen

The Home Screen is the first screen you'll see upon power up. Use the **Home Screen** sub menu to choose and customize the Home Screen. The numbered items in the illustration to the right are described in more detail in the following table.



The names and descriptions in the following table apply only to the **VZW Full Layout** Home Screen. Other layouts are available through the **Home Screen** sub menu.

Item	Name	Function
1	**Title Bar**	Indicates such things as signal strength, battery charge status, network mode, messages, and ringer status.

Item	Name	Function
2	Most Recent Apps	Indicates The five most recently used applications. Use the OK/Navigation key to highlight/launch any applications that appear.
3	Service Mode	Indicates the present mode of service, such as Home Service or Roaming. The time of day also appears in the display.
4	E-mail/ SMS	Indicates the number of E-mail or SMS messages in your Inbox.
5	Pending appointments	Indicates names/times of pending appointments.
6	News/ Data Card	Access news through Internet Explorer. Acess the data card through file explorer.
7	Profile	Indicates the currently selected profile.
8	Menu Bar	Displays left and right soft key commands.

Display screen



The display screen is any screen other than the Home Screen. Display screen format does not change. However, Title Bar and Menu Bar content change according to the current menu or application. The display screen contains some or all of the elements in the following table.

Item	Name	Function
1	Title Bar	Indicates the current application, menu, or sub menu, battery charge status, signal strength, network mode, and ringer status.
2	Application Display	Contains menus, sub menus, Internet content, and application work areas.
3	Menu Bar	Displays left and right soft key commands.

Icons

Various icons may appear in your Smartphone's display or Home Screen during operation. The following table lists these icons as well as their descriptions.

Icon	Definition
	Signal strength, more bars indicate a better signal.
	GPS is on for location.
	Global Positioning Service (GPS) for 911 is active.
	Indicates the ringer is set to **On**.
	Indicates the ringer for the selected profile is set to **Vibrate** or **Off**.
	Indicates your Smartphone is charging.
	Indicates that the 1X high speed data protocol is supported.
	Receive and transmit icon that appears in the Home Screen whenever your Smartphone transmits or
	Indicates the battery power level. More bars equal more power.
	You have a new **SMS** message or **E-mail** message in your **Inbox**.
E-mail(1)	You have a new E-mail message. The number in parenthesis indicates the number of messages.
	You have a missed call. Also, the right soft key changes from **Contacts** to **Call History**.
	Your Smartphone is in Roaming mode.
	You are in speakerphone mode.

Your Smartphone's keypad

The keys of the SCH-i600 are functionally divided into three groups. The **Navigation** keys, **Alpha-numeric** keypad, and **Hot keys** (on each side of the Smartphone).

1.) Navigation: Scroll through menus and lists, confirm changes that you've entered, and interact with menus that appear in the display.



2.) Alpha-numeric:
Enter text, numbers, and symbols.

3.) Hot keys: Located on both sides of the Smartphone. Used to launch applications, increase volume, power the Smartphone on and off, and more.



Navigation/OK key

Use any of the four directional arrows on the Navigation/OK key to scroll through and highlight items, menus, and programs in a list or on the Internet. Once an item, link, or menu is highlighted, press OK to perform the function related to the selection.

Home key

Press to return to the Home Screen from any menu, sub-menu, or application.

Back/Clear key

Press to close the current menu and return to the previous menu or screen. While in any text edit screen, you can also press to backspace and clear text. Press and hold to clear all text in the field.

Soft keys

The soft keys are located at the top of your Smartphone's keypad, on either side of the Navigation key. The function of each soft key is defined by what appears above it in the menu bar, which is the bottom portion of the display screen.

- Press the left soft key ( ) to perform the function that appears directly above it in the menu bar.
- Press the right soft key ( ) to perform the function that appears directly above it in the menu bar.

Alpha-Numeric keypad

Use the alpha-numeric keypad to place calls. You can also enter text, numbers, and symbols into messages or information into **Contacts** using the alpha-numeric keypad. Use multi-press as the standard method for entering text, or **T9** to write messages faster.

Hot keys

There are additional keys on both sides of the Smartphone that perform a variety of useful functions.

Voice Memo key

Briefly press the Record/Memo key ( ) to display any recordings that you have made. You have the option of recording a new memo or playing back an old memo.

- Once the record list appears in the display, press the left soft key ( ) **Record** to record a new memo.

1. Press the right soft key ( ) **Menu** to display a pop-up menu containing **Play**, **Record**, **Rename**, or **Delete**.
2. Press the up or down arrows (▲ or ▼) on the Navigation key to highlight your selection.
3. Press OK to confirm your choice.

Volume Up/Down keys

Press and release the up or down volume keys to adjust earpiece volume from any screen.

Internet/Voice Signal key

Briefly press the Internet/Voice Signal key ( ) to launch **Internet Explorer** and go to the most recently visited web page. Press and hold until you hear a tone, then release it to launch **Voice Signal**. Voice Signal enables you to dial numbers, open applications, look up contacts, and much more using voice recognition technology.

Quick List key

1. Briefly press the Quick List key ( ) to display the functions listed in the following table.

Tip: Press and hold the **Quick List** key while the flip is closed to turn on the backlight for the front LED display.

Tip: Press and hold the **Quick List** key while the flip is open to turn the Radio function on or off. Radio functionality refers to the RF capabilities of your Smartphone. With the radio function off, you cannot place or receive calls.

Function	Description
Device lock	Set your Smartphone to lock after a specified period of time. You'll be asked to set and confirm a password to enable this feature.
Key lock	Lock your Smartphone's keypad to prevent accidental dialing. Press the soft key **Unlock**, then press to unlock your Smartphone's keypad.
Radio off	Turn the RF transmitting capabilities of your Smartphone on or off, enabling you to use your Smartphone's PDA capabilities in areas where phone use is prohibited.
Normal	Selects the **Normal** volume profile.
Silent	Selects the **Silent** volume profile.
Meeting	Selects the **Meeting** volume profile.
Loud	Selects the **Loud** volume profile.
More...	Displays the additional profiles of **1 Headset** and **2 Speakerphone**.

2. Press the up or down arrows (or) on the navigation key to scroll through the functions.
3. Once a function is highlighted, press the left soft key ( ) to enable the function.

Set up Voicemail

All unanswered calls to your Smartphone are sent to voicemail, even if your Smartphone is turned off. Therefore, you'll want to set up your voicemail and personal greeting as soon as you activate your Smartphone. Your service provider has assigned your voicemail number to the 1 key.

1. Press and hold 1 to dial your voicemail. ***86** and **Calling...** appear in the display.
2. When the system answers, enter your password then press #.
3. Follow the system prompts to set up your voicemail.

Note: You can also press *, 8 TUV, 6 MNO, then SEND to dial voicemail.

Contact Customer Care

verizonwireless.com is open 24 hours a day for customer service, general information, even shopping. But just in case, be sure to keep the following numbers handy.

- Customer Service (6am–11pm): *611 SEND
- 24-Hour Technical Support (24 hrs.): *611 SEND

Make and answer calls

1. At the Home Screen, enter the number you wish to call using the keypad.
2. Press SEND.

Make a call from your Contacts list

Contacts are entries that you create to store names, numbers, and other information for people or groups of interest. If you've already entered information into your Contacts list, you can recall and dial the contact easily. See "Contacts" on page 38 for information on creating contacts.

1. At the Home Screen, press the right soft key **Contacts**.
2. Press ▲ or ▼ until the contact that you wish to call is highlighted.

Tip: To quickly locate a name, press (or multi-press) any key on the keypad that corresponds to the first letter of the contact's name.

3. When the desired contact is highlighted, press OK. Details for the contact appear in the display.
4. If the entry contains more than one number, use ▲ or ▼ to highlight the desired number.
5. Press SEND or OK to call the number.

Answer Calls

1. Make sure that the Smartphone is turned on.
2. When you receive an incoming call, the **Incoming** screen appears in the display. press **Accept** to answer the call or **Reject** to silence the ringer and let the call go to voicemail.

Use the speakerphone in a call

Speakerphone amplifies the caller's voice and routes it through the speaker on back of the handset. You can then place your Smartphone nearby and converse hands free.

1. While in a call, press the right soft key ( ) **Menu**. A pop-up menu appears in the display.
2. Use the navigation key to highlight **Speakerphone**, then press OK. The speakerphone icon ( )appears in the upper portion of the display. You can now hear the person you are calling over the speaker.

Tip: Press and hold while in a call to activate the speakerphone.

Navigate menus

Navigation of your Smartphone's menus and sub-menus is similar to that of a Windows-based PC.

1. Press the left soft key, labeled **Programs** at the Home Screen.
2. Use the navigation key to scroll through the menus. To move to the next page of menus, ensure **More...** is highlighted (when available), then press OK.
3. Once you arrive at a the desired menu or sub menu, press OK.

Navigate using shortcuts

Due to dynamics of i600 menus, a list of menus and sub menus (along with their corresponding menu numbers) is not provided in this user guide.

- You can also shortcut to a menu by pressing the left soft key **Programs**, and then the corresponding menu and sub menu numbers.

For example, press the left soft key **Programs**, then press 8 TUV to launch **ActiveSync**.

Optional SD Card

The open slot on the right side of the Smartphone is for use with an optional SD (secure digital) card. SD cards come in a variety of sizes and can hold up to 1 gigabyte of data. Download and use applications, games, and more using the enhanced storage capacity of the SD card.

Tip: The SD Slot is an I/O port, which allows Bluetooth, 802.11x, phone attachments, and more, enabling expansion and making your Smartphone the ultimate communicator.

Transfer data to the SD Card from your computer

1. Insert the SD Card (label side up) into the slot on the right side of the Smartphone. The beveled edge should be facing toward the top of the Smartphone.
2. Insert your Smartphone into the desktop cradle and synchronize the Smartphone with your PC via ActiveSync.
3. Open Windows Explorer then highlight the application, game, or folder that you wish to transfer to the SD Card.
4. Highlight and copy the file(s) or folder(s) to your computer's clipboard.
5. Using the ActiveSync menu, click the **Explore** icon to open the **Mobile Device** folder.

6. Double-click on the Smartphone folder to open it up.

7. Double-click the Storage Card folder to open it up. Any contents of the SD Card appear in the display.

8. Locate the folder or subfolder where you wish to paste the files that you've copied.

9. Press **Ctrl-V** on your computer to paste the files or folders that you copied to your computer's clipboard to the Smartphone SD Card.

Use the SD Card

Once you've transferred files from your computer to the SD Card using ActiveSync, you can access games or applications that have been transferred to your SD Card.

For example, if you've transferred any multimedia files onto your SD Card that are compatible with Windows Media Player, simply open Windows Media Player from the Home Screen and select the media file that you wish to play. There is no need to look or browse your Smartphone for the SD Card. The SD Card is recognized when it is installed.

Remove the SD Card

1. Press in on the card with your fingernail until you hear a click, then quickly release. The card pops out of the slot approximately one quarter of an inch.
2. Grasp the exposed section of the card and pull it out with your fingers.

Settings

The **Settings** menu is the control center for a wide variety of functions. Use the **Settings** menu for such things as changing ring tones, editing profiles, and displaying information about your Smartphone's hardware and software.

Call Options

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then use the navigation key to highlight **Settings**.
3. Press OK. **Call options** is highlighted.
4. Press OK. The **Call Options** sub-menus in the following table appear in the display.

Sub-menu	Function
Call answer	Pick the method that you wish to answer calls. Options are **Send key**, **Folder open**, **Any key**.
Provide voice privacy notifications	Check the box to allow voice privacy notifications to be sent via the network.
Auto answer	Set your Smartphone to answer calls after a specified period of time. Options range from Off to 10 seconds.
Phone number	View the phone number assigned to your Smartphone.
Voice mail number	Enter or view the voice mail number assigned to your Smartphone.
Country code	Enter the country code for your Smartphone. The country code for the U.S.A. is 1.
Area code	Enter the area code specific to your location.

5. Use the navigation key to highlight a sub-menu.

6. Press ◀ or ▶ to choose from available options.
7. Press the left soft key (···) **Done** when finished or press the right soft key (···) **Cancel** to return to the **Settings** menu.

Sounds

Use the **Sounds** sub-menu to set the desired tones for such things as reminders, new messages, and alarms.

1. At the Home Screen, press the left soft key (···) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then use the navigation key to highlight **Settings**.
3. Press OK, then press ▼ until **Sounds** is highlighted.
4. Press OK, then use ▲ or ▼ to highlight any of the sub-menus in the following table.

Sub-menu	Function
Ring tone	Selects the default ring tone for calls.
Reminders	Selects the ring tone or melody for reminders.
New e-mail	Selects the ring tone or melody for new e-mail.
New SMS	Selects the ring tone or melody for new SMS messages.
New voice message	Selects the ring tone or melody for new voice messages.
New instant message	Selects the ring tone or melody for new instant messages.
New channel message	Selects the ring tone or melody for new channel messages.
Alarm clock	Selects the ring tone or melody for an alarm.
Exclamation	Selects the ring tone or melody for an exclamation.
Question	Selects the ring tone or melody for a question.

Sub-menu	Function
Warnings	Selects the ring tone or melody for a warning.
Keypad control	Selects the type of sound emitted when a key is pressed.

5. Once you arrive at an option, press ◀ or ▶ to select the desired tone.
6. Press the left soft key (▪▪▪) **Done** when finished, or press the right soft key (▪▪▪) **Menu** then select **Cancel** to return to the **Settings** menu.

Profiles

The Profiles sub-menu allows you to select and modify available profiles. There are separate profiles for normal use, when in meetings, when using the headset, and so on. Each profile controls such properties as ringer volume and ringer type for when you receive a call, when an alarm sounds, and other essential functions.

1. At the Home Screen, press the left soft key (▪▪▪) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then use the navigation key to highlight **Settings**.
3. Press OK, then press ▼ until **Profiles** is highlighted.
4. Press OK, then press ▲ or ▼ to highlight a profile.

Headset and **Speakerphone** profiles cannot be selected directly. These options are selected automatically when you plug in a headset or use the speakerphone option.

1 Normal
2 Silent
3 Meeting
4 Loud

5 Headset

6 Speakerphone

5. Once a profile is highlighted, press the left soft key (···) **Done** to activate the profile.

When a profile is highlighted, you can also press the right soft key (···) **Menu** to display a pop-up menu from which you can choose further options such as **Edit**, **Select**, **Cancel**, or **Reset to default**. See the following section entitled “Edit a profile” for information on how to edit profiles.

Edit a Profile

You can change properties such as ring type, notification method, and volume level for any of the six profiles.

1. Highlight the profile that you wish to edit, then press the right soft key (···) **Menu**. A pop-up menu appears in the display with **Edit** highlighted.
2. Press OK. The list of profile settings in the following table appear in the display.
3. Press ▲ or ▼ to highlight the profile setting that you wish to edit.

Profile setting	Function
Name	Rename the profile.
Ring type	Select from several different ring types for incoming calls.
Ring volume	Select the default ringing volume for incoming calls.
Alarm type	Select whether you wish an alarm to vibrate, vibrate then sound, increase in volume, and more.
Alarm volume	Select the alarm for alarms.
Notification type	Select how you are notified of incoming messages.

Profile setting	Function
Notification volume	Select the volume of notifications for incoming messages.
System sound volume	Set the volume for alerts, keypresses, and other sounds that are made when your Smartphone responds to an action.

4. Press ◀ or ▶ to change the selection for the highlighted setting.
5. Press the left soft key (▪▪▪) **Done** when finished, or press the right soft key (▪▪▪) **Cancel** to return to the **Profiles** sub-menu.

Home Screen

The Home Screen sub-menu allows you to choose the layout, color scheme, wallpaper, and other Home Screen options.

1. At the Home Screen, press the left soft key (▪▪▪) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then use the navigation key to highlight **Settings**.
3. Press OK, then press ▼ until **Home Screen** is highlighted.
4. Press OK, then press ▲ or ▼ to highlight any of the options in the following table.

Home Screen setting	Function
Home screen layout	Select from several options that affect the format and layout of your Home Screen.
Color scheme	Select a color schemes for your Home Screen.

Home Screen setting	Function
Background image	Select a wallpaper for your Home Screen and add background images by copying images to the Smartphone via ActiveSync®.
Time out	Select the desired time interval before the display automatically goes to the Home Screen (after a period of inactivity).

5. Once an option is highlighted, press ◀ or ▶ to display and select alternatives for that option.
6. Press the left soft key (▪▪▪) **Done** to save your setting, or press the right soft key (▪▪▪) **Cancel** to return to the **Profiles** sub-menu.

About

The **About** sub-menu contains information regarding your Smartphone's operating system, processor, total and available memory, and other system properties.

1. At the Home Screen, press the left soft key (▪▪▪) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then use the navigation key to highlight **Settings**.
3. Press OK, then press ▼ until the **About** sub-menu is highlighted.
4. Press OK to display information about your Smartphone.
5. Use the up and down navigation keys (▲▼) to display all of the information.
6. Press the left soft key (▪▪▪) **Done** when finished.

Accessibility

Use the Accessibility sub-menu to set system fonts, time-out intervals between key presses, and other accessibility options.

1. At the Home Screen, press the left soft key (▪▪▪) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then use the navigation key to highlight **Settings**.
3. Press OK, then press ▼ until the **Accessibility** sub-menu is highlighted.
4. Press OK. The accessibility sub-menus in the following table appear in the display.

Sub-menu	Function
System font size	Choose the font size for many of your phone's functions.
Multipress time out	Set the time before the text editor advances to the next character when using multipress.
Confirmation time out	Set the time to respond to prompts before the Smartphone returns to its prior state.
In-call alert volume	Set the volume of alerts for incoming calls while in a call.

Although the **System font** affects the text size of menus and submenus, it doesn't control the size of embedded text in applications such as **Internet Explorer** or **ActiveSync®**.

5. Press ▲ or ▼ to highlight a sub-menu.
6. Press ◀ or ▶ to choose between settings for the highlighted sub-menu.
7. Press the left soft key (▪▪▪) **Done** when finished.

Data Connections

Use the Data Connections sub-menu to configure connection properties for the Internet, WAP, and data/fax.

1. At the Home Screen, press the left soft key (⋯) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then use the navigation key to highlight **Settings**.
3. Press OK.
4. Press ▼ until the **Data Connections** sub-menu is highlighted, then press OK.
5. Press ▲ or ▼ to scroll through and highlight any of the data connection types in the following table.

Sub-menu	Function
Data/Fax mode	Set the data/fax mode.
Internet connection	Choose the method for connecting to the Internet
Work connection	Select the work connection type, if available.
WAP connection	Select the WAP connection type, if available.
Secure WAP connection	Select the secure WAP connection type, if available.

6. Press ◀ or ▶ to choose settings for the highlighted sub-menu.
7. Press the left soft key (⋯) **Done** when finished.

Edit Connections and Options

1. Press the right soft key ( ) **Menu** while in the **Data Connections** sub-menu to display a pop-up menu containing the following.

Pop-up menu item	Function
Edit Connections	Choose your dial-up service provider.
	Choose your VPN (Virtual Private Networking) connection for service.
	Choose your proxy connection.
Options	Choose the number of times your Smartphone attempts to redial the number for your service provider.
	Choose the amount of idle time for your connection before the session is terminated.
	Choose between your Corporate Network, the Internet, a secure or unsecure WAP network.
Cancel	Cancel and return to the Settings menu.

2. Use the navigation keys to choose your setting.
3. Press the left soft key ( ) **Done** when finished. You're returned to the **Data Connections** sub-menu.

Date and Time

Use the **Date and Time** sub-menu to set your time zone, date, time, turn the alarm on and off, and to set a recurring alarm time.

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then use the navigation key to highlight **Settings**.

3. Press OK, then press ▼ until the **Date and Time** sub-menu is highlighted
4. Press OK, then press ▼ to highlight any of the options in the following table.

Tip: When setting the time, press any alpha-numeric key at the **AM** or **PM** indicator to switch from AM - PM, or PM - AM.

Date and time option	Function
Time zone	Set the time zone.
Date	Set the date.
Time	Set the time.
Alarm	Turn the alarm on or off.
Alarm time	Set the time that you wish the alarm to come on.

5. Use ◀, ▶, or the keypad to change values for the highlighted option.
6. Press the left soft key ( ) **Done** when finished or the right soft key ( ) **Cancel** to return to the **Settings** menu.

Owner Information

Use the **Owner Information** screen to enter personal information and notes.

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then use the navigation key to highlight **Settings**.
3. Press OK, then press ▼ until the **More...** sub-menu is highlighted.
4. Press OK. **Owner Information** is highlighted.

5. Press OK, then press ▲ or ▼ to browse and highlight the **Name**, **Telephone number**, **E-mail address**, and **Notes** fields.
6. Once a field is highlighted, use the keypad to enter information for the field.
7. Press the left soft key (▪▪▪) **Done** when finished.

Power Management

Use the **Power Management** sub-menu to view the status of the main battery, set the backlight time-out, and perform other functions to regulate your Smartphone's power usage.

1. At the Home Screen, press the left soft key (▪▪▪) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK. **Settings** is highlighted.
3. Press OK, then press ▼ until **More...** is highlighted.
4. Press OK, then press ▼ until **Power Management** is highlighted.
5. Press OK. The options listed in the following table appear in the display.

Option	Function
Main battery	View remaining battery power.
Brightness level	Set the brightness level of the display.
Backlight time out	Set the amount of time the display screen backlight remains illuminated after a period of inactivity.
Power saving time out	Set the amount of time before the display screen goes blank after a period of inactivity.
In-call screen time out	Set the amount of time before the display screen goes blank while in a call.

6. Press ▲ or ▼ to highlight an option.
7. Once the desired option is highlighted, press ◀ or ▶ to change settings for the option.
8. Press the left soft key (▪▪▪) **Done** when finished.

Regional Settings

You can customize language, date style, number, time and currency format options using **Regional Settings** submenu.

1. At the Home Screen, press the left soft key (▪▪▪) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then use the navigation key to highlight **Settings**.
3. Press OK, then press ▼ until the **More...** sub-menu is highlighted.
4. Press OK, then press ▼ until **Regional Settings** is highlighted.
5. Press OK. The options listed in the following table appear in the display.

Option	Function
Language	Set the default language.
Locale	Set the local language for your Smartphone. For example: US English or UK English.
Short date style	Choose how the short date appears in the display.
Long date style	Choose how the long date appears in the display.
Time format	Set the format for the Home Screen clock.
Positive number	Choose the decimal type and other settings for positive numbers.

Option	Function
Negative number	Choose the decimal type and other settings for negative numbers.
Positive currency	Choose the positive currency symbol, position, and more.
Negative currency	Choose the positive currency symbol, position, and more.

6. Press ▲ or ▼ to highlight an option.
7. Press OK to view available settings for the highlighted option.
8. Press ▲ or ▼ to scroll between settings.
9. Press ◀ or ▶ to change the highlighted setting.
10. Press the left soft key ( ) **Done** when finished.

Remove Programs

To free up more space, you can remove programs that you've downloaded from your Smartphone.

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then use the navigation key to highlight **Settings**.
3. Press OK, then press ▼ until **More...** is highlighted.
4. Press OK, then press ▼ until **Remove Programs** is highlighted.
5. Press OK. Any programs that you've downloaded appear in the display.
6. Press ▼ until the program that you wish to remove is highlighted.

7. Press the right soft key (▪▪▪) **Menu**. A pop-up menu appears in the display with **Remove** highlighted.
8. Press OK. The program is removed and a confirmation message appears in the display.

Security

The Security sub-menu allows you to define phone lock settings, to enter special numbers, reset your Smartphone, and initialize the memory.

1. At the Home Screen, press the left soft key (▪▪▪) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then use the navigation key to highlight **Settings**.
3. Press OK, then press ▼ until **More...** is highlighted.
4. Press OK, then press ▼ until **Security** is highlighted.
5. Press OK, then press ▼ to highlight any of the options in the following table.

Option	Function
Enable Phone Lock	Define the period of inactivity before your Smartphone locks. You'll need to create and confirm a password in this sub-menu before Phone Lock can be enabled.
Emergency Numbers	Enter up to three Emergency Numbers. Default Emergency Numbers are 911, *911, and #911. Emergency Numbers can be dialed even while the Smartphone is locked.
Phone Reset	Enter your Phone Lock password to reset the Smartphone to default values. This affects all settings for your Smartphone. The default password is the last four digits of your telephone number unless Phone Lock password is set.

Option	Function
Initialize Memory	Enter your Phone Lock password to re-initialize the memory in your Smartphone.

6. Once the desired option is highlighted, press OK to enter that option's sub-menu.
7. Press the left soft key (▪▪▪) **Done** when finished or press the right soft key (▪▪▪) **Cancel** to return to the **Security** sub-menu.

Phone Settings

The **Phone Settings** sub-menu controls NAM and roam settings, alerts for reminding you of elapsed time while in a phone conversation, connect and disconnect alert tones, voice privacy settings, and more.

1. At the Home Screen, press the left soft key (▪▪▪) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then use the navigation key to highlight **Settings**.
3. Press OK, then press ▼ until **More...** is highlighted.
4. Press OK, then press ▼ until **Phone Settings** is highlighted.
5. Press OK, then press ▼ to highlight any of the options in the following table.

Option	Function
NAM/ Roam Mode	**NAM1**: Select if your Smartphone has one line. **NAM2**: Select if your Smartphone has two lines.

Option	Function
Beep/ Alert	**Minute beep**: If set to On, your Smartphone beeps every 60 seconds that you are in a call. **Connect tone**: If set to On, a tone sounds when you connect a call. **Disconnect tone**: If set to On, a tone sounds when you disconnect a call.
Version	View the software versions for your Smartphone and PDA, as well as the hardware version for the phone.
Other	**Voice privacy**: Set to Enhanced to hide your name and number from the recipient of the call. **GPS:** Location on fully enables GPS functionality while 911 only enables GPS functionality for emergency calls only. **Time:** Select Auto to update time via the server. Manual is not updated. **USB:** External Data Call or ActiveSync.

6. Press ▼ to highlight an option.
7. Once the desired option is highlighted, press OK to enter that option's sub-menu.
8. Press ▲ or ▼ to select from the available settings.
9. Press the left soft key (▪▪▪) **Done** when finished.

TTY/TDD

Your Smartphone is fully TTY/TDD compatible. Connect the TTY/TDD equipment to the headset jack, which is located on the left side of the Smartphone above the volume keys. Before you can use your Smartphone with a TTY/TDD device, you'll need to enable TTY/TDD functions in the Smartphone.

1. At the Home Screen, press *↑, *↑, 8TUV, 8TUV, 9WXYZ. The TTY **Settings** menu appears in the display.
2. Press ▶ to select **On**, then press the left soft key (▪▪▪) **Save**. TTY/TDD is enabled.

Your Personal Digital Assistant

The i600 is not just a phone; it is an integrated communication device. It has the power of a mobile phone and the intelligence of a Personal Digital Assistant. The i600 is loaded with familiar Microsoft® pocket applications, like Pocket Outlook, Pocket Internet Explorer, MSN® Messenger, Windows® Media™ Player 8 for Smartphone, and ActiveSync®. You don't have to learn new software to use all the phone's features.

Calendar

Calendar allows you to set an appointment for a specific date and time, and to be reminded of the appointment in advance.

Make a new appointment

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **Calendar** is highlighted.
2. Press OK to open the Calendar.
3. Press the right soft key( ) **Menu**. A pop-up menu appears in the display with **New** highlighted.
4. Press OK, then enter the subject of the appointment using the keypad.
5. After you enter the subject, press ▼ until **Start date** is highlighted.
6. Enter the start date for the appointment using the keypad, then press ▼ until **Start time** is highlighted.

Tip: To change from AM to PM (or vice versa), press any key on the keypad when AM or PM is highlighted.

7. Continue to complete the necessary fields. Press ▼ or ▼ to move between fields.
8. Press the left soft key (▪▪▪) **Done** when finished or the right soft key (▪▪▪) **Cancel** to return to the previous menu.

Weekly, Monthly, and Agenda Views

Calendar offers the convenience of three different views. Cycle between views by pressing the left soft key's current label at the **Calendar** main screen. Use the navigation keys to highlight specific dates or times in each view.

- **Week** view is a list of the appointments for the week.
- **Month** view is an overview of the current month, with one week at a time.
- **Agenda** view is a monthly view of the current month

Calendar options

You can define your calendar's weekly starting day (Sunday or Monday), length of the week view, whether you wish the week numbers to be visible in monthly view, and the default amount of time that you wish to be reminded for an appointment in advance.

1. At the Home Screen, press the left soft key (▪▪▪) **Programs**, then press ▼ until **Calendar** is highlighted.
2. Press OK to open the **Calendar**.
3. Press the right soft key (▪▪▪) **Menu**. A pop-up menu appears in the display with **New** highlighted.

4. Press ▼ until **Options** is highlighted, then press OK. The options listed in the following table appear in the display.

Option	Function
First day of the week	Choose between a Sunday or a Monday start date.
Week view	Choose between a 5 or 7 day week.
Month view	Choose to have week numbers visible in the Month view.
Set reminders	Choose the default amount of time that you wish to be reminded of an appointment in advance.

5. Press ▲ or ▼ to browse the list of options.
6. Once an option is highlighted, press ◀ or ▶ to change your preferences for that option.
7. Press OK to select a check box, if necessary.
8. Press the left soft key (▪▪▪) **Done** when finished or the right soft key **Cancel** to return to the previous menu.

Contacts

Your Smartphone can store contact information that contains over fourty-three elements, ranging from the name and number to details as such as personal web page and job title.

Make a new contact

1. At the Home Screen, press the right soft key (▪▪▪) **Contacts**.
2. Press the left soft key (▪▪▪) **New**. The contact form containing the elements listed in the following table, appears in the display.

3. Press ▼ to page down and view all elements of the form. Use the keypad to enter text and data.

First name	Home fax	City	ZIP
Last name	Assistant phone	State/Province	Country
Work phone	Radio phone	ZIP	Notes
Mobile phone	E-mail2	Country	Birthday
Home phone	E-mail3	Home address Street	Anniversary
Email	Web page	City	Spouse
Work2 phone	File as	State/Province	Children
Home2 phone	Job title	ZIP	Assistant
Categories	Department	Country	
Pager	Company	Other address street	
Car phone	Office address: Street	City	
Work fax		State/Province	

4. Press the right soft key (▪▪▪) **Menu** to display a pop-up menu where you can insert a pause, insert a wait, or **Cancel** and return to the **Contacts** list.
5. Press the left soft key (▪▪▪) **Done** when finished.

View Contacts

1. At the Home Screen, press the right soft key (▪▪▪) **Contacts**. If you've entered any contact information, a list of contacts appears in the display.
2. Press ▲ or ▼ to browse the contact list.
3. When the desired contact is highlighted, press OK to view details about the contact.

Beam a contact via IR

You can beam contact information to a compatible device via the infrared port. The distance between the two devices must be unobstructed and within a range of 3 inches to 3 feet. Also, ensure both devices have infrared reception enabled.

1. At the Home Screen, press the right soft key (▪▪▪) **Contacts**.
2. Use ▲ and ▼ to browse the contact list. When the contact that you'd like to beam via IR is highlighted, press the right soft key (▪▪▪) **Menu**.
3. Press ▼ until **Beam Contact** is highlighted, then press OK.
4. Align the IR ports of both devices and press the left soft key (▪▪▪) **Beam**. The contact is sent to the other device via IR and a confirmation message appears in the display.

Make a call from Contacts

1. At the Home Screen, press the right soft key (▪▪▪) **Contacts**.
2. Press ▼ to highlight the contact that you'd like to call, then press SEND/PTT. Your Smartphone dials the contact.

Categories

You can assign a contact to one of 3 categories and then filter (view) the contacts assigned to those categories later. This is helpful if you have a large number of contacts and only want to view those of a certain type.

Assign a category to an existing contact

1. At the Home Screen, press the right soft key (···) **Contacts**. Your list of contacts appear in the display.
2. Press ▼ to highlight the contact of your choice, then press OK.
3. Press the left soft key (···) **Edit**, then press ▼ to scroll down to **Categories**.
4. Press OK, then use ▲ or ▼ to highlight the category of your choice. Available categories are as follows:

- **Business**
- **Miscellaneous**
- **Personal**

5. Press OK once the category of your choice is highlighted. A checkmark appears next to your selection.
6. Press the left soft key (···) **Done**. You're returned to the previous menu.
7. Press the left soft key (···) **Done** again to return to the **Contacts** list.

Filters

Once you've assigned a category to a contact, you can filter them so that only contacts associated with the selected category appear. This is helpful if you have a large number of contacts and wish to view only those of a certain type.

1. At the Home Screen, press the right soft key **Contacts**. Your list of contacts appear in the display.

2. Press the right soft key ( ) **Menu**. A pop-up menu appears in the lower part of the display.

3. Press ▼ until **Filter** is highlighted, then press OK. A list of filters appears in the display.



4. Press ▼ to highlight the filter of your choice, then press OK. Contacts assigned to the selected category appear in the display.

Program Speed Dial numbers

After you've added names or numbers to your **Contacts** list, you can then assign a speed dial location (keypad number) to the contact. Once a speed dial location is assigned, you simply press and hold the assigned key or keys on the keypad to dial the number. There are 98 Speed Dial locations available (2-99), Speed Dial locations 0 and 1 are reserved and not available for assignment.

1. At the Home Screen, press the right soft key **Contacts**.

Note

If **Call History** appears as the right soft key (instead of **Contacts**), this means that you have a missed a call. Press the right soft key **Call History** and view the number to clear **Call History** from the Home Screen.

2. Use the navigation key to highlight the contact that contains the number you wish to assign to speed dial.

3. Once the contact is highlighted, press OK.

4. Use the navigation key to highlight the number that you wish to assign to speed dial.
5. Press the right soft key **Menu**, **Add Speed Dial** is highlighted.
6. Use the navigation key to highlight the **Keypad assignment** field.
7. Use the navigation key to display available (open) keypad locations.
8. Once the desired keypad location appears in the display, press the left soft key **Done** to assign the number to the speed dial key.

Use Speed Dial (One-Touch Dialing)

- At the Home Screen, press and hold the key to which you've assigned the Speed Dial number. The number is dialed.

Use Speed Dial (Two-Touch Dialing)

If you've assigned a number a two-digit location (such as 10 or 12), the method for speed dialing the number varies from One-Touch Dialing.

1. At the Home Screen, press and release the first number of the Speed Dial location.
2. Press and hold the second number of the Speed Dial location until the number is dialed.

Microsoft® ActiveSync®

Once ActiveSync is installed on a desktop/laptop PC and your SCH-i600, you can use it to synchronize data between the two devices. ActiveSync is already installed on your Smartphone, but you'll have to install it on your PC before you can exchange information between the two devices.

Important! Do not attach the USB cable until ActiveSync is installed on the PC.

Minimum PC requirements

ActiveSync comes with your Smartphone on a CDROM. Following are the minimum resources that must be present on your PC before you can install ActiveSync:

- Microsoft Windows XP, Windows 2000, Windows Millennium Edition, Windows NT Workstation 4.0 with SP6 or later, or Windows 98
- Microsoft Outlook 98 or later required for synchronization to the desktop or portable computer of e-mail, calendar, contacts, tasks, and notes. (Outlook 2002 recommended)
- Microsoft Internet Explorer 4.01 SP1 or later
- Hard-disk drive with 12 to 65 MB of available hard-disk space (actual requirements will vary based on selection of features and user's current system configuration)
- Infrared port or USB port (available for Windows 98, Windows Me, Windows 2000, and Windows XP only)
- CD-ROM drive
- VGA graphics card or compatible video graphics adapter at 256 color or later
- Keyboard
- Microsoft Mouse or compatible input device

Install ActiveSync

1. Place the ActiveSync CD in the CDROM drive on your computer. After a short time **Getting started with your Smartphone** appears in the display.
2. Click **Start Here**.
3. Click **Install ActiveSync 3.x**.
4. Click **Install**. The following message appears in the display.


Installation Message -- Web Page Dialog
You are about to install a product from the Smartphone Companion CD.
Select "Run this program from its current location" and click OK
OR
Click "Open".
OK

5. Click **OK**. The file download box appears in the display.
6. Click **Open**. The Microsoft ActiveSync setup dialogue box appears in the display.
7. Click **Next**. You're prompted to select the installation folder for ActiveSync.
8. Click **Next** to install ActiveSync to the default folder, or click **Change** to select a different destination for the program.
9. If you selected **Change**, follow the prompts to direct installation of ActiveSync to the folder of your choice, otherwise proceed to step 10.

10. Click **Next**. ActiveSync program files are copied to your hard drive in the default folder.

- After the files are copied to your hard drive, the **Get Connected** dialogue box appears in the display. Use the instructions in following connection methods that best suit your needs to connect your Smartphone and computer via ActiveSync.

ActiveSync options menu

The ActiveSync options menu allows you to configure the various applications which allow you to share data between your Smartphone and PC.

1. At the Home Screen, press the left soft key (⋯) **Programs**, then press ▼ until **ActiveSync** is highlighted.
2. Press OK, then press the right soft key (⋯) **Menu**. A pop-up menu appears in the display with **Connect via IR** highlighted.
3. Press ▼ to highlight **Options**, then press OK. The following menu items appear in the display:

1 **Calendar**
2 **Contacts**
3 **Inbox**
4 **Connection**
5 **PC Settings**
6 **Schedule**
7 **Conflicts**

4. Press ▼ to highlight the menu item of your choice, then press OK. The following sections describe Calendar menu options in more detail.

Upload and access media files

Before you can upload .jpg and .wav files to your Smartphone, you'll need to create the folders for each file type (in your Smartphone) using **ActiveSync** and Microsoft Windows **Explorer**. Once the folders are created and media files are uploaded to the appropriate folder, the files can be accessed through the Smartphone user interface.

When saving files via ActiveSync, first verify that enough space is available on your phone. To view **Available Storage**, press the left soft key ( ) **Programs**, then open the **More**, **Settings**, and **About** sub menus respectively.

Create media folders on your Smartphone

1. Place your Smartphone in the docking cradle with the flip open. The Smartphone synchronizes with the computer and the **Microsoft ActiveSync** application box appears in the computer's display.
2. Click on the **Explore** icon. An **Explorer** style window opens.

3. Right click on the **Smartphone** icon ( ), then select **Explore** from the dropdown list. Your Smartphone's files and folders appear in the display.
4. Double-click the **IPSM** folder ( ). Contents of the **IPSM** folder appear in the display.
5. Double-click the **Application Data** folder. Contents of the **Application Data** folder appear in the display.
6. Click on the **File** menu and select **New Folder** from the dropdown list.
7. Name the new folder **Sounds**.

8. Click on the **File** menu and select **New Folder** from the dropdown list.

9. Name the new folder **Home**. You are now ready to upload media files to your Smartphone from your PC.

Upload media files

Once you've created the appropriate folders on your Smartphone using the ActiveSync interface as outlined in the previous section, you can move the files from the PC to your Smartphone using Windows **Explorer**.

1. Right click on your computer's **Start** button and select **Explore**. The contents of your computer's hard drive appear in the display.

2. Locate and highlight the media files on your computer that you wish to transfer to your Smartphone, then press **CTRL-C** to copy the files to your computer's clipboard.

3. Locate the **Smartphone** icon ( ) and explore the Smartphone's contents by clicking on the + to the left of the icon.

- If the file that you copied is a .jpg file, open the **Home** folder on your Smartphone and press **CTRL-V** to paste the .jpg file (or files) into the **Home** folder.
- If the file that you copied is a .wav file, open the Sounds folder on your Smartphone to, then press CTRL-V to past the .wav file (or files) into the Sounds folder.
- The target folder for each media type (.jpg or .wav) in your Smartphone's folder hierarchy is as follows:
  JPEG files - Mobile Device/Smartphone/IPSM/Application Data/Home
  WAV files
  Mobile Device/Smartphone/IPSM/Application Data/Sounds

Access and use JPEG files

Once you've uploaded .jpg files to the appropriate folders on your Smartphone, you can use the jpeg as a background image for the Home Screen.

1. At the Home Screen, press the left soft key ( ) **Programs**, then press , , .
2. Use the navigation key to highlight the selection field beneath **Background image**.
3. Use the navigation key to display the name of the file previously uploaded to your Smartphone.
4. Press the left soft key **Done**. The image will now appear as a background image on your Home Screen.

Access and use WAV files

Once you've uploaded .wav files to the appropriate folders on your Smartphone, you can use the .wav file as a ring tone.

1. At the Home Screen, press the left soft key () **Programs**, then press , , . The **Ring tone** field is highlighted.
2. Use the navigation key to display the name of the .wav file that you wish to use as a ring tone.
3. Press the left soft key **Done**. The selected .wav file will now play whenever you receive an incoming call.

Use ActiveSync via IR

1. At the Home Screen, press the left soft key () **Programs**, then press until **ActiveSync** is highlighted.

2. Press OK, then press the right soft key ( ) **Menu**. A pop-up menu appears in the display with **Connect via IR** highlighted.
3. Ensure the IR ports on your Smartphone and computer are facing each other within a distance of 3 inches to 3 feet, then press OK.
4. After a short time, **Connected** appears in the display of your Smartphone. The **New Partnership Wizard** appears in the display of your computer.
5. Select **Standard Partnership** or **Guest Partnership** and click **Next**.

Tip: Select **Standard Partnership** to synchronize Calendar items or E-mail. **Guest Partnership** does not allow synchronization options.

6. Next, you are given the option to synchronize with your local computer or to synchronize with your local computer and the Microsoft Mobile Information Server.

You must have access to a Microsoft Mobile Information Server with Server ActiveSync to synchronize with a server. You will also need to have the necessary information to configure your connection with the server. Contact Verizon Wireless if you don't have this information at hand.

7. Select Synchronize with this desktop computer and click **Next**.

Browse your files with ActiveSync

Once you've synchronized your Smartphone with your PC, you can browse the files on your with the ActiveSync application on your PC.

1. In the ActiveSync application on your PC, click on the **Explore** icon. The Mobile Device folder opens with the sub folder My Smartphone shown in the display.
2. Double-click on the My Smartphone folder. Several folders appear in the display.
3. Open the sub folders and view their contents as you would using Microsoft Explorer.

Smartphone folders

Your Smartphone has file and system folders much like your PC. Using ActiveSync, you can view these folders and their contents in the familiar format of a Windows Explorer environment.

Calendar

The **Calendar** folder within ActiveSync allows you to configure settings for the calendar application when you synchronize your Smartphone with a PC. If this is the first time you've entered the ActiveSync application, you'll be asked to create a new partnership when you enable calendar synchronization (see "Partnerships" on page 58 for more information).

1. At the Home Screen, press the left soft key (⋯) **Programs**, then press ▼ until **ActiveSync** is highlighted.
2. Press OK, then press the right soft key (⋯) **Menu**. A pop-up menu appears in the display with **Connect via IR** highlighted.
3. Press ▼ to highlight **Options**, then press OK. **1 Calendar** is highlighted.

4. Press OK. The following options appear in the display.

   ☐ Synchronize Calendar

   Include past:

   2 Weeks

5. With **Synchronize Calendar** highlighted, press OK to place a check mark in the box.

6. Press ▼ to highlight the Include past: field.

- **1Day**
- **3Days**
- **1Week**
- **2Week**
- **1 Month**

7. Press ◀ or ▶ to select from the options listed. Press the left soft key (⋯) **Done** when finished.

Contacts

The **Contacts** folder within ActiveSync allows you to select whether you wish your contacts to be synchronized with the PC whenever synchronization occurs.

1. At the Home Screen, press the left soft key (⋯) **Programs**, then press ▼ until **ActiveSync** is highlighted.

2. Press OK, then press the right soft key (⋯) **Menu**.

3. Press ▼ to highlight **Options**, then press OK.

4. Press ▼ to highlight **Contacts**, then press OK. The following appears in the display:

   ☐ Synchronize Contacts

5. Press OK.

6. Press the left soft key (⋯) **Done** when finished.

Inbox

1. At the Home Screen, press the left soft key (⋯) **Programs**, then press ▼ until **ActiveSync** is highlighted.
2. Press OK, then press the right soft key (⋯) **Menu**.
3. Press ▼ to highlight **Options**, then press OK.
4. Press ▼ to highlight **Inbox**, then press OK**.** The following appears in the display:

   ☐ Synchronize Inbox
   Include past:
   3 Days
   Limit e-mail size to:
   .5k
5. With **Synchronize Inbox** highlighted, press OK to place a check mark in the box.
6. Press ▼ until **Include past** is highlighted. **Include past** allows you to set a time limit on the data that will be synchronized when you connect with the server.
7. Press ◀ or ▶ to select one the following options:

   3 Days
   1 Week
   2 Weeks
   1 Month
   All
8. When finished, press ▼ to highlight **Limit e-mail size to:** Limit e-mail size to Allows you to limit the size of e-mail items that are synchronized when you connect with the server.

9. Press ◀ or ▶ to select from the following options:

   .5k
   1K
   5K
   All
   Header Only

10. Press the left soft key (▪▪▪) **Done** when finished.

Connection

The **Connection** folder within ActiveSync allows you to enter and preset information necessary to connect to your server.

1. At the Home Screen, press the left soft key (▪▪▪) **Programs**, then press ▼ until **ActiveSync** is highlighted.
2. Press OK, then press the right soft key (▪▪▪) **Menu**.
3. Press ▼ to highlight **Options**, then press OK.
4. Press ▼ to highlight **Connection**, then press OK. The options listed in the following table appear in the display.

Option	Function
Username	Enter the username for your account on the server.
Password	Enter the password for your account on the server.
Domain	Enter the domain information for your server.
Save password	Press OK to check this box. Your password is memorized each time you synchronize.
Server name	Enter the server name, which is furnished by your service provider.
Logging	Enable logging only under the direction of a Customer Care representative

5. Press ▼ until the desired option is highlighted.

6. Press ◀, ▶, and the corresponding keys on the alpha-numeric keypad to enter and select information.
7. Press the left soft key (···) **Done** when finished.

PC Settings

The **PC Settings** folder within ActiveSync allows you to set default settings for the PC when synchronizing to the server.

1. At the Home Screen, press the left soft key (···) **Programs**, then press ▼ until **ActiveSync** is highlighted.
2. Press OK, then press the right soft key (···) **Menu**.
3. Press ▼ to highlight **Options**, then press OK.
4. Press ▼ to highlight **PC Settings**, then press OK. The following options appear in the display.

   ☐**Automatically start sync when connected using:**
   USB Default
   ☐**Include PC sync remotely when synchronizing**
   Connect To:
   No partnership created
5. Press ▼ to highlight an option.
6. Press OK, ◀, or ▶ to select your preference for the highlighted option.
7. Press the left soft key (···) **Done** when finished.

Schedule

The **Schedule** folder within ActiveSync allows you to synchronize ActiveSync automatically with your computer at various intervals, whether or not you're connected to your PC via cable.

1. At the Home Screen, press the left soft key (⋯) **Programs**, then press ▼ until **ActiveSync** is highlighted.
2. Press OK, then press the right soft key (⋯) **Menu**.
3. Press ▼ to highlight **Options**, then press OK.
4. Press ▼ to highlight **Schedule**, then press OK**.** The following options appear in the display.

- When connected to the PC, synchronize with the server every 5 min, 15 min, 30 min, 60 min, 2 hours, or 4 hours.
- When not connected to the PC, synchronize with the server every 5 min, 15 min, 30 min, 60 min, 2 hours, or 4 hours.

5. Press ▼ to highlight an option, then press OK select the check box next to that option.
6. Press ▼ to highlight the preferences for that option, then press ◀ or ▶ to modify the preferences for the selected option.
7. Press the left soft key (⋯) **Done** when finished.

Conflicts

The **Conflict** folder within ActiveSync allows you to globally define those items that are replaced when there is a data conflict. A data conflict occurs when information has changed on your Smartphone or PC since the last synchronization.

1. At the Home Screen, press the left soft key (⋯) **Programs**, then press ▼ until **ActiveSync** is highlighted.
2. Press OK, then press the right soft key (⋯) **Menu**.
3. Press ▼ until **Options** is highlighted, then press OK.
4. Press ▼ until **Conflicts** is highlighted, then press OK. The following options appear in the display.

   Replace on device - Replace data on your Smartphone if data on both your Smartphone and the PC has changed since the last synchronization.

   Replace on server - Replace data on your PC if data on both your Smartphone and the PC has changed since the last synchronization.
5. Press ◀ or ▶ to select your **Conflicts** preference.
6. Press the left soft key (⋯) **Done** when finished.

Partnerships

A partnership is a set of rules governing file transfer and synchronization between your Smartphone and PC. There are two types of partnerships, **Standard** and **Guest**.

- A **Standard partnership** is used to synchronize data and transfer files between your device and the PC.
- A **Guest partnership** can only be used to transfer files between your device and the PC, not synchronize.

Create a New Partnership

After you install ActiveSync and the necessary USB drivers, you'll need to create a new partnership.

1. Connect the data cable between your Smartphone and PC.
2. Double-click on the ActiveSync icon on your computer's desktop. If this is the initial launch of ActiveSync, **New Partnership** appears in the display.
3. Select **Standard** or **Guest** partnership and click **Next**.
4. Enter a unique name for your device and click **Next**.
5. Select the applications that you wish to synchronize and click **Next**, and then click **Finish**.

Your Smartphone and PC begin synchronization. This may take some time, depending on the amount of information to be synchronized. When the process is complete, disconnect the data cable from your Smartphone and close ActiveSync.

Text, symbols, and numbers

You can enter text, numbers and symbols into messages, form fields, interactive applications, games, and on the Internet.

Enter text using T9

There are 2 methods for entering text; **T9** and **Multi-tap**. Multi-tap is the conventional method of entering text, while T9 uses advanced software to greatly increase writing speed.

Activate T9

- While at any text entry screen, press and hold until **t9**, **T9**, or **T9** appears in the upper right corner of the display.

T9 modes

Each of T9's three modes is indicated by the following icons in the upper right corner of the display.

T9 - Uppercase. Any words that you enter will be in uppercase, or all capital letters.

T9 - Initial caps. Only the first word of each sentence is in capital letters.

t9 - Lowercase. Any words that you enter will be in lower case letters.

- To cycle through **T9** modes, briefly press while in **T9** mode.

Use T9

The fastest and easiest way to enter text into messages is using **T9** Text Input. To spell a word using **T9**, you only have to press one key per letter of the word that you're spelling. For example, to spell **Samsung** you would press each of the following keys *only once*:

It's best not to look at the screen while writing a word. As you enter letters, occasionally matches to other words appear in the display.

The T9 dictionary

Occasionally, the word that appears isn't the one that you had in mind. If this happens, simply press 0 (while the word is underlined) to cycle through available words in the **T9** dictionary.

Enter symbols

1. To enter symbols while writing a word or letter, press and hold # until the **Symbols** screen appears in the display.
2. Press ▲, ▼, ◀, or ▶ as necessary to highlight the symbol that you wish to enter into your message.
3. Press the left soft key ( ) **Done** when the symbol of your choice is highlighted. The selected symbol is placed into your message.

Enter punctuation

- To enter a period while entering text, press 1 .

Enter spaces after words

- To enter a space after a word, thereby accepting the word and proceeding to the next word, press .

Enter text using Multi-tap

Activate multi-tap

- While at any text entry screen, press and hold until **ABC**, **ABC**, or **abc** appears in the upper right corner of the display.

Enter text

- The conventional method for entering text is called multi-tap, which requires up to four key presses for each letter, depending on the letter that you wish to enter.
- For example, to enter “z,” press four times in succession. To enter an “a” however, only one press of is required.
- Once the desired letter appears in the display, pause briefly until the line beneath the letter disappears. Continue to enter other letters as desired.
- Press to enter a space and continue on to the next word.
- Press to enter a period.

Multi-tap modes

Multi-tap mode is indicated by the following icons in the upper right corner of the display.

ABC - Uppercase only. Any letters that you enter will be in uppercase, or all capital letters.

ABC - Initial caps. Only the first word of each sentence is in capital letters.

abc - Lowercase. Any words that you enter will be in lower case letters.

- To cycle through multi-tap modes, briefly press while using multi-tap.

Enter symbols, spaces, and punctuation in T9

- Press and hold until a pop-up menu appears in the display. Use the navigation key to highlight the symbol or punctuation to insert into your message, then press the left soft key ( ) **Done**. The selected symbol or punctuation appears in the display.
- Briefly press whenever you want to enter a space after a letter or word.

Enter numbers

1. Press and hold until **123** appears in the upper right corner of the display.
2. Enter numbers using the alpha-numeric keypad.

Messaging

Your Smartphone can receive voicemail, SMS, and e-mail messages. When a new message is received, a tone sounds and a notification appears in the display.

Message Types

The following types of messages are supported by your Smartphone.

- Voicemail
- SMS Text
- E-mail

Voicemail

When you receive a new voicemail, a notification appears in the display. If you have multiple voicemail messages, the notification displays the number of new or unread messages received.

Set up voicemail

1. Press and hold to dial the voicemail system.
2. Follow the recorded prompts to set up your voicemail.

Check voicemail

1. Press and hold . Your Smartphone dials the voicemail system.
2. When you're connected to the voicemail system, enter your password and press
3. Follow the recorded prompts to listen to your voicemail.

SMS Text Messages

You can send and receive text messages to other users with SMS capability. Text messaging, also known as SMS (Short

Message Service) can be sent from one device to another by addressing the message to the recipient's phone number.

Create a new text message

Tip: Text messages can be sent to up to 10 people at once. Simply recall the names from your **Contacts** list and add them to the **TO:** field while composing a message.

1. At the Home Screen, press the left soft key ( ) **Programs**. **Inbox/SMS** is highlighted.
2. Press OK, then press the left soft key ( ) **New**. The **New Message** screen appears in the display.
3. Enter the phone number of the recipient in the **To:** field, or press the right soft key ( ) **Menu** (**Add To:** is highlighted). Press OK to review and select recipients from your **Contacts** list.
4. Press ▼ to highlight the **Cc:** field. Enter the number of the person or persons that you wish to copy on the message.

Tip: Press and hold * to cycle between **T9**, **123**, and **Abc** modes. Briefly press * to cycle between different options within each mode.

5. Press ▼ to highlight the **Subj:** field. Enter a subject for the message using the keypad.
6. Press ▼ to move the cursor to the message body field. Enter your message using the keypad.

Tip: Press the right soft key **Menu** while composing a message to display several options such as inserting a short, pre-composed message, and more. See the following section entitled **Text message options** for more information.

Tip: Use T9 text entry to write messages, it's much faster than the traditional multi-tap method.

7. When you're finished writing the message, press the right soft key **Menu**.
8. Press ▼ to highlight **Send Message** and press OK.

SMS messages are limited to 160 characters. If you send an SMS message of more than 160 characters, it is broken up and sent in separate messages until the entire message is delivered. Charges apply for the delivery of each message according to your billing plan.

Tip: You can send e-mail messages while in SMS mode. Simply enter the e-mail address of your recipient (instead of the phone number) in the **To:** field.

Text message options

Press the right soft key ( ) **Menu** while composing a message to display the options in the following table.

Some options may not be available depending upon your location within the **New Message** screen. These options will appear in a lighter text than other options.

Option	Function
Add To	Add up to ten contacts from your **Contacts** list to the recipient field of the message
Insert Text	Insert pre-composed short phrases or replies into your message
Insert Recording	Record a memo and insert it into your message
Message Options	Allows you to request a message delivery notification
Postpone Message	Exit composition of the message. The message is saved as a draft in the **Drafts** folder
Send Message	Send the message to the recipients in the **To:** and **Cc:** fields

Option	Function
Cancel Compose	Cancels composition of the message (after confirmation)

E-mail

You can send and receive e-mail to anyone with a valid e-mail address through the **Inbox/SMS** menu. E-mail is not limited to 160 characters as in the case with SMS text messages.

E-mail setup

You can set up your Smartphone to connect to any e-mail account if you have necessary information about the account. Contact your service provider for setup information specific to your mobile account. Contact your Internet Service Provider or look in your computer's e-mail client for setup information specific to your home e-mail service.

1. At the Home Screen, press the left soft key ( ) **Programs**. **Inbox/SMS** is highlighted.
2. Press OK. The **Inbox** screen appears in the display.
3. Press the right soft key **Menu**, then press ▼ until **Options** is highlighted.
4. Press OK. A list of Inbox options appear in the display.
5. Press ▼ to highlight **E-mail Setup**, then press OK.
6. Press the right soft key ( ) **Next**. The next page of the **E-mail Setup** screen appears in the display.

7. Press ▼ to highlight any of the options listed in the following table.

Option	Function
Your name	Enter your name using the keypad.
E-mail address	Enter your E-mail address using the keypad.
Server type	Press ◀ or ▶ to select **POP3** or **IMAP4**.

8. Once an option is highlighted, press ◀, ▶, or use the keypad to change or enter information.
9. Press the right soft key ( ) **Next** to display the next page of options.
10. Press ▼ to highlight any of the options listed in the following table.

Option	Function
Incoming mail server	Enter the necessary information furnished by your service provider.
Outgoing mail server	Enter the necessary information furnished by your service provider.
Network	Press ◀ or ▶ to select from the following options: **The Internet** **Secure WAP Network** **WAP Network** **My Corporate Network**

11. Once an option is highlighted, press ◀, ▶, or use the keypad to change or enter information.
12. Press the right soft key ( ) **Next** to display the next page of options.

13. Press ▼ until the desired option (listed in the following table) is highlighted.

Option	Function
Username	Enter the username for your E-mail account.
Password	Enter the password for your E-mail account.
Domain (if necessary)	Enter the domain name for your E-mail account, if necessary.
Save password	Save the password for your E-mail account.

14. Once an option is highlighted, press ◀, ▶, OK, or use the keypad to change or enter information.
15. Press the right soft key ( ) **Next** when finished. **Setup complete!** appears in the display.
16. Press the right soft key ( ) **Finish** to complete the E-mail setup process.

Send and Receive E-mail

After you've gone through the E-mail Setup process, you can send and receive e-mail messages easily.

1. At the Home Screen, press the left soft key ( ) **Programs**. **Inbox/SMS** is highlighted.
2. Press OK. The **Inbox** screen appears in the display.
3. Press the left soft key ( ) **New** to open the **New Message** screen.
4. Enter the E-mail address of the recipient in the **To:** field using the keypad.

To cycle between text entry modes, press and hold *. To display the **Symbols** screen (for the @ symbol), press and hold #. Use the navigation keys to highlight a symbol, then press the left soft key ( ) to insert the symbol into your message.

5. Press ▼ to highlight the **Cc:** field. Use the keypad to enter the e-mail address of any recipient (or recipients) that you wish to copy on this e-mail.
6. Press ▼ to highlight the **Subj:** field. Use the keypad to enter a subject for the e-mail.
7. Press ▼ to move the cursor to the message body field.
8. Compose your message using the keypad.
9. Once you've finished composing your message, press the right soft key ( ) **Menu**. A pop-up menu appears in the display.
10. Press ▼ until **Send Message** is highlighted, then press OK. You're returned to the **Inbox** screen.
11. Press the right soft key ( ) **Menu** again. A pop-up menu appears in the display.
12. Press ▼ until **Send/Receive E-mail** is highlighted, then press OK. Your Smartphone dials the e-mail server number and the message is delivered to the intended recipients.

Postpone a message

You can compose a message and send it later. The message is saved in the **Drafts** folder for later use.

1. While composing a message, press the right soft key **Menu**.
2. Press ▼ until **Postpone Message** is highlighted, then press OK. **Saved in Drafts** briefly appears in the display.

Recall and send a postponed message

1. At the Home Screen, press the left soft key ( ) **Programs**. **Inbox/SMS** is highlighted.
2. Press OK. The **Inbox** screen appears in the display.
3. Press the right soft key ( ) **Menu**.
4. Press ▼ until **Show Folders** is highlighted, then press OK. The **Folders** screen appears in the display.
5. Press ▼. **Drafts** is highlighted.
6. Press the left soft key **Select**. Any messages saved to the **Drafts** folder appear in the display.
7. Press ▼ until the message you'd like to recall is highlighted, then press OK.
8. Press the left soft key **Send**. Your message is sent to the intended recipients.

View folders in your Inbox/SMS menu

The Inbox/SMS menu contains folders similar to the e-mail application on your PC. You can save messages to these folders, recall and send them again at a later date, or keep them for later viewing.

E-mail and SMS messages reside in the same inbox and are identical in appearance.

1. At the Home Screen, press the left soft key ( ) **Programs**. **Inbox/SMS** is highlighted.
2. Press OK. The **Inbox** screen appears in the display.
3. Press the right soft key ( ) **Menu**.

4. Press ▼ until **Show Folders** is highlighted, then press OK. The **Folders** screen with the contents in the following table appears in the display.

Folder	Description
Deleted Items	Messages deleted from other folders are sent here. You can restore deleted messages, delete individual messages, or empty the entire folder altogether.
Drafts	Postponed messages are sent to the **Drafts** folder where they can later be recalled and sent to the intended recipient. You can edit the message before sending, or delete the message, thereby sending it to the deleted
Inbox	New incoming messages are saved here. You can delete, reply, forward, mark for download, or mark the message as read.
Outbox	Messages are stored in the **Outbox** until they are sent. Messages that could not be sent remain in the Outbox where you can view and/or delete them later.
Sent Items	Messages that have been sent are stored here. You can **Reply**, **Forward**, **Delete**, or **Mark as Read**.

Tip: If your Smartphone does not respond or send/receive e-mail, go back to the Home Screen and re-establish an Internet connection. While the connection is live, go back to the **Inbox/SMS** menu and press the right soft key ( ) **Menu**. Select **Send/Receive E-mail** from the pop-up menu.

Voice Signal

Voice Signal is advanced speech recognition software that can be used to activate a wide-variety of functions on your Smartphone. Voice Signal software automatically voice activates all contacts in your Phone Book for voice dialing and Phone Book searching, no pre-recording or training needed. Speak phone numbers naturally to dial, and use voice commands to launch applications and navigate phone menus.

Voice Signal Features

The following is a list of functions that you can perform using Voice Signal speech recognition on your Smartphone.

- **Digit Dial:** Dial by saying the phone number
- **Name Dial:** Dial by saying any name in your Contacts list
- **Quick Dial:** Dial by saying custom voice tags for any name in your Contacts list
- **Name Lookup:** Open the contact record for any name in your **Contacts** list
- **Open App:** Open any application installed on your device

Digit Dial

Digit Dial allows you to dial any phone number by simply speaking the digits into the Smartphone. No training is necessary, and Digit Dial is programmed to understand natural speech.

1. Press and hold for two seconds.
2. After a brief pause, a list of optional commands appears in the display and the audio prompt “Please say a command” plays through the speakerphone.

3. Say “Digit Dial” at a distance of 3-12 inches from the Smartphone in a natural voice.
4. “Please say the number” plays through the speakerphone.
5. Say the area code and number that you wish to dial into the microphone. Say the number naturally.
6. The number that you said is repeated through the speakerphone and your Smartphone dials the number.
7. If Voice Signal is not sure of the number that you said, a list of possible matches appears in the display.
8. You’re asked to confirm the correct number as Voice Signal displays the results. Say “Yes” or “No” to confirm or reject the number when prompted.

Name Dial

To use Name Dial, you’ll need to have some entries in your Contacts list. See “Contacts” on page 38 for information on creating a Contacts list.

1. Press and hold for two seconds.
2. A list of commands appears in the display and the audio prompt “Please say a command” plays through the speakerphone.
3. Say “Name Dial” at a distance of 3-12 inches from the microphone.
4. “Please say the name” plays through the speakerphone.
5. Say the name exactly as it is displayed in your contacts list, first name followed by last name.

6. The contact name appears in the display. If your contact has more than one number, such as a mobile number and a home number, you're prompted for which location.
7. Say the location.
8. The location is repeated through the speakerphone and your Smartphone dials the number.

Train Quick Dial

1. At the Home Screen, open the Voice Signal Setup menu and then select **Record Names**. Your list of contacts appears in the display and you have the choice to **Train** or **Play** the name of the contact.
2. Press **Train**. You're prompted to say the name.
3. Say the name at a distance of 3-12 inches from the microphone.
4. "Did the recording sound okay?" appears in the display.
5. Press **Yes** to proceed or **No** if the recording was unacceptable. You're returned to the Contacts list. A red checkmark appears next to the "trained" contact.

Use Quick Dial

1. Press and hold for two seconds.
2. A list of commands appears in the display and the audio prompt "Please say a command" plays through the speakerphone.
3. Say "Quick Dial" at a distance of 3-12 inches from the microphone.
4. "Who would you like to call" appears in the display and the audio prompt is played through the speakerphone.

5. Say the contact name exactly as it is has been “trained.” If you haven’t trained any of your contacts for Quick Dial, you’re prompted to do so.
6. The Smartphone displays the contact, you hear your recorded Quick Dial entry through the speakerphone, and your Smartphone dials the number.

Name Lookup

To perform a name lookup, you’ll need to have some entries in your Contacts list. See “Contacts” on page 38 for information on creating a contacts list.

1. Press and hold for two seconds.
2. A list of commands appears in the display and the audio prompt “Please say a command” plays through the speakerphone.
3. Say “Name Lookup” at a distance of 3-12 inches from the microphone. “Please say the name” plays through the speakerphone.
4. Say the name exactly as it is displayed in your Contacts list, first name followed by last name.
5. The contact name appears in the display with other information that you’ve entered for that contact.

Open App

The example that follows instructs you how to open Internet Explorer. However, you can open any application on your Smartphone using Voice Signal.

1. Press and hold for two seconds.
2. A list of commands appears in the display and the audio prompt “Please say a command” plays through the speakerphone.
3. Say “Open Internet Explorer” at a distance of 3-12 inches from the microphone.
4. Internet Explorer opens and is directed to the last web page visited.

The last web page visited is stored in your system cache. If you have not yet used Internet Explorer to browse the web, you’re directed to your service provider’s home page.

Voice Signal Settings

You can adjust the settings and preferences for Voice Signal by opening **Voice Signal Setup** from the Home Screen. In the **Voice Signal Setup** menu you can train, edit, and delete Quick Dial entries, adapt the Digit Dial feature, turn the “Did you say?” choice lists on and off, adjust speed and accuracy, and select applications for launching by voice.

Understanding Roaming

Roaming

Roaming occurs when you travel outside the designated coverage area. Your Smartphone automatically switches to roaming and the roaming icon (▲)appears in the display. Your Smartphone can roam on other digital networks. When you are roaming, extra charges may apply when making or receiving a call.

During roaming, some of your Smartphone's features may not be available. Also, when roaming, your Smartphone requires additional power from the battery and may require frequent recharging.

Roaming Options

The following roaming options are available:

- **Home only** - Your Smartphone is available for normal operation only in the designated coverage area.
- **Automatic-A** - The preferred roaming list is used to acquire service. If no preferred systems are found, any digital "A" system is acquired.
- **Automatic-B** - The preferred roaming list is used to acquire service. If no preferred systems are found, any digital "B" system is acquired.

Contact your service provider for information regarding preferred systems.

Call History

When you place a call, miss, or receive a call, a record of the call is saved in **Call History**. Your Smartphone retains a history of the types of calls listed in the following table.

Call History type	Description
No Filter	Displays all calls received, sent, or missed.
Missed	Displays any missed calls.
Outgoing	Displays all outgoing calls made from your Smartphone.
Incoming	Displays any incoming calls that were answered.
Find Contact	Allows you to select an entry from the contacts and then displays any call information related to the contact.

View your Call History

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **Call History** is highlighted.
2. Press OK. A list of numbers appear in the display.

View information about a call

Call History retains information such as the duration, date and time, whether the call was **Incoming**, **Outgoing**, or **Missed**.

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **Call History** is highlighted.
2. Press OK, then press ▼ to highlight the desired number.

3. Once the desired number is highlighted, press OK. The options listed in the following table appear in the display.

Call History Option	Function
_____ **call**	Indicates the type of call, whether it was missed, dialed, or received.
Method	If the caller is in your **Contacts** list, the type of call is listed here (M-Mobile, W-Work, etc.). This option **only** appears if the caller is in your **Contacts** list.
Duration	The duration of the call.
Date	The date of the call.
Time	The time of the call.

4. Press ▼ to page down the display and view all of the information, if necessary.

5. Press the left soft key ( ) **Save** to save the information to your **Contacts** list, or press the right soft key ( ) **Menu** to display the options listed in the following table.

Call History Option	Function
Find Contact	See if the number exists within your **Contacts** list
E-mail	Send an e-mail to the number
Delete	Delete the call from **Call History**
Save	Save the number to your **Contacts** list

6. Press ▼ to highlight an option. Press OK to enter the highlighted option's sub-menu.

Call History Icons

When you view Call History, an icon to the left of the number indicates the type of call.

Indicates a **Missed** call

Indicates an **Outgoing** call

Indicates a **Received** call

Make a Call from Call History

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **Call History** is highlighted.
2. Press OK, then press ▼ to highlight the desired number.
3. Press SEND to call the highlighted number.

Create a new contact from Call History

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **Call History** is highlighted.
2. Press OK, then press ▼ to highlight the number for which you wish to create a contact.
3. Press the left soft key ( ) **Save**. The **Select Contact** menu appears in the display with **New Item** highlighted.
4. Press OK. Enter information for the contact.

- Press the left soft key ( ) **Insert** (when applicable) to insert the phone number of the **Call History** number you are adding to your **Contacts**.

5. Press the left soft key ( ) **Done** when finished.

Delete a Call History entry

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ to highlight **Call History**.
2. Press OK, then press ▼ to highlight the number you wish to delete.
3. Press the right soft key ( ) **Menu**. A pop-up menu appears in the display.
4. Press ▼ to highlight **Delete** and press OK. You're notified that this will delete the selected entry.
5. Press the left soft key ( ) **Yes** to delete the entry or the right soft key ( ) **No** to return to the previous menu.

Delete all Call History entries

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **Call History** is highlighted.
2. Press OK, then press the right soft key ( ) **Menu**. A pop-up menu appears in the display.
3. Press ▼ to highlight **Delete List**, then press OK. You're notified that this will delete all entries in your **Call History** list.
4. Press the left soft key ( ) **Yes** to delete the list or the right soft key ( ) **No** to return to the previous menu.

Caller ID

Caller ID alerts you to who is calling by displaying the caller's phone number. If you call someone who has this feature, your phone number appears in their display as well. If the caller's name and number are stored in your Phone Book, their name also appears with the number.

If you have a large number of contacts in your Phone Book, Caller ID is somewhat slower in displaying names and numbers.

Block caller ID

- Press *, 6 MNO, 7 PQRS, then dial the phone number.

Call Waiting

Incoming calls can be picked up, even when you are on an existing call. When on a call and another call is received, a tone sounds and a message appears in the display. If the caller is stored in your Contacts list, their name also appears in the display.

1. Press the left soft key ( ) **Accept** to pick up the call or the right soft key ( ) **Wait** to ignore the call and continue with your conversation.

If you press **Wait**, the call is diverted to voicemail.

When you accept a new call, the original caller is put on hold.

2. Press SEND to switch back to the original caller.

Three-way Calling

1. At the Home Screen, enter the number you wish to call, then press .
2. After the first caller picks up, dial the second person and press .
3. When the person answers, press again to connect all three parties.

If one of the parties in the conversation ends the call, the remaining parties stay connected. However, if you initiated the call and are the first to hang up, all calls are disconnected.

Tasks

Tasks are short to-do notes about anything you wish. Create a single task, or a task list, then mark your tasks complete once they're finished.

Create a new task

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then press ▼ until **Tasks** is highlighted.
3. Press OK. The **Tasks** entry screen appears in the display, with **Enter new task here** highlighted.
4. Press ▲ to enter a new task.
5. Enter task information using the keypad. Press OK when finished.

Mark a Task complete

Use a check to indicate when a task is complete.

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then press ▼ until **Tasks** is highlighted.
3. Press OK. Your list of tasks appear in the display.
4. Press ▼ to highlight a task.
5. Press the left soft key ( ) **Complete** or OK to place a check mark next to a completed task.

Activate a completed task

You can reactivate a task after it has been marked complete.

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then press ▼ until **Tasks** is highlighted.
3. Press OK. Your list of tasks appear in the display.
4. Press ▼ to highlight a task.
5. Press the left soft key ( ) **Activate** or OK to activate a completed task.

Delete a Task

When a task is competed, it can be deleted from the task list.

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then press ▼ until **Tasks** is highlighted.
3. Press OK. Your list of tasks appear in the display.
4. Press ▼ until you highlight a completed task.
5. Press the right soft key ( ) **Delete** to delete the task.

Voice Notes

You can record a phone number, parking location, or a simple reminder using Voice Notes.

Make a recording

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then press ▼ until **Voice Notes** is highlighted.
3. Press OK. The Voice Notes screen appears in the display.
4. Press the left soft key ( ) **Record**. Your Smartphone begins recording and the elapsed time appears in the display.
5. **Record** your information, then press the left soft key () **Stop** when finished. The recording is named a default of **Recording #**.

To record quick note, press on the left side of the Smartphone to display the recording menu. Press again to begin recording.

Rename a recording

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then press ▼ until **Voice Notes** is highlighted.
3. Press OK to open **Voice Notes**. A list of recordings appears in the display.
4. Press ▼ until the recording you wish to rename is highlighted.
5. Press the right soft key ( ) **Menu**. A pop-up menu appears in the display.
6. Press ▼ until **Rename** is highlighted, then press OK.
7. Press to backspace and clear the current name for the recording. Use the keypad to enter a new name for the recording.
8. Press the left soft key ( ) **Done** when finished or the right soft key ( ) **Cancel** to exit and return to the previous menu.

Other Applications

In addition to the applications that come with your Smartphone, you can also download and install other applications as needed. The SCH-i600 contains 25MB of memory to allow for continued expansion. Expand your Smartphone's capabilities even more with an optional SD Card. An SD (Secure Digital) card can store up to a gigabyte of data for use with your Smartphone. See "Use the SD Card" on page 19 for more information about the SD Card.

Pocket Internet Explorer

Your Smartphone has a robust version of this popular web browser in the convenience of a hand-held device. Pocket Internet Explorer on your Smartphone has much of the functionality of its PC counterpart. You can add bookmarks for frequently visited web pages, modify connection settings, language preferences, cookie permissions, and more.

Use Pocket Internet Explorer to view web pages on your Smartphone two different ways:

- Download web pages then synchronize with ActiveSync
- Connect to the Internet and view web pages online

While browsing you can also download new files and programs. If you are using Microsoft Internet Explorer version 4 or later, your favorites can be synchronized to your Smartphone.

Launch Pocket Internet Explorer

1. At the Home Screen, press the left soft key (▪▪▪) **Programs**, then press ▼ until **Internet Explorer** is highlighted.
2. Press OK. A list of Favorites appears in the display.

3. Press ▼ to highlight the favorite that you'd like to visit on the Internet, then press OK.
4. Your Smartphone dials the service provider and connects to the Internet.

Tip: If Internet Explorer is slow in responding or does not function at all, you may need to empty the cache file. See below.

Empty the cache

While browsing the web, pages that you visit sometimes leave behind files in your Smartphone. The file types and their descriptions are outlined in the following table. To delete any or all of these files, use steps 1 - 5 below.

File type	Description
Temporary files	Previously viewed pages of the current browsing session.
Cookies	Files created by websites that store information on your computer, such as your preferences while visiting that site.
History	Shortcuts to pages viewed during previous browsing sessions.

1. At the Home Screen, press the left soft key (···) **Programs**, then press ▼ until **Internet Explorer** is highlighted.
2. Press OK, then press the right soft key (···) **Menu**. A pop-up menu appears in the display.
3. Press ▼ or ▲ to highlight **Options**, then press OK.
4. Press ▼ or ▲ to highlight **Memory**, then press OK.
5. Press ▼ or ▲ to highlight the file type that you wish to clear from the cache, then press the right soft key (···) **Clear**. Press the left soft key (···) **Yes** to confirm.

Add Favorites

When you find a web page that contains useful or interesting information, it can be saved as a favorite, which is also known as a bookmark.

1. While viewing the web page that you'd like to save as a favorite, press the right soft key ( ) **Menu**.
2. Press ▼ until **Add Favorite** is highlighted, then press OK.
3. Press to delete the default text for the web page if desired, then enter a name for the web page using the keypad.
4. Press the left soft key ( ) **Add** to add the web page to your list of favorites.

Add a new folder

You can add new folders to your Favorites sub-menu, then add as many favorites to the folders as you like.

1. While in **Favorites**, press the right soft key ( ) **Menu**. A pop-up menu appears in the display.
2. Press ▼ until Add Folder is highlighted, then press OK.
3. Enter a name for the new folder using the keypad.
4. Press the left soft key ( ) **Add** when finished.

MSN Messenger

Log onto Microsoft MSN® Messenger and chat with others right from your Smartphone. The mobile version of MSN Messenger is the same as the PC version.

Using your Internet connection, you can quickly send instant messages to your list of online buddies, or interact with multiple people at the same time. The chat window lets you read and write messages, and notifications alert you if others are trying to get in touch. “My Text” lets you store and recall frequently used messages so you can respond without composing a reply.

MSN Messenger is a MSN Passport service and requires a Passport, Hotmail®, or MSN account.

Login to MSN Messenger

1. At the Home Screen, press the left soft key (▪▪▪) **Programs**, then press ▼ until **MSN Messenger** is highlighted.
2. Press OK. The **MSN Messenger** Sign in screen appears in the display.
3. Press the left soft key (▪▪▪) **Sign In** to log in with your Passport, Hotmail, or MSN account.
4. **Sign-in Name:** is highlighted. Enter your sign-in name for the Passport, Hotmail, or MSN account using the keypad.

   Tip: Press and hold # to display the **Symbols** screen. Use the ▲, ▼, ◀, or ▶ until the symbol you wish to enter is highlighted. Press the left soft key **Done** or OK to insert the symbol into your login or password field.

5. Press ▼ to highlight **Password:**, then enter your password for the account using the keypad.
6. Press ▼ to highlight **Remember my password:**. If you wish for MSN Messenger to remember your password the next time you sign in, press OK.

7. Press the left soft key ( ) **Sign In** to log in to MSN Messenger, or the right soft key ( ) **Cancel** to return to the previous menu.

Add a buddy to your contact list

A buddy is another MSN Messenger user who shares similar interests. MSN Messenger automatically notifies a buddy when the other is online.

1. Once you've logged in to MSN Messenger, press the right soft key ( ) **Menu**. **Add Contact** is highlighted.
2. Press OK, then enter the e-mail address of the buddy you wish to add to your contact list.

Only valid Passport, Hotmail®, or MSN accounts can be added to your contact list.

3. Press the right soft key ( ) **Next**.

An instant message is sent to the e-mail address of the buddy you've added notifying them that you've added them to your contact list. They are given the opportunity to accept your request or block further requests. A message appears in your Smartphone display that confirms or denies the request.

4. Press the left soft key ( ) **Done** when finished.
5. Your buddy's e-mail address appears under **Online** or **Not Online** in your Smartphone display, depending on their status.

Start a chat session

You can chat with another person if they're online and you'll both receive your responses in "real time," which means that there is very little delay. You can even join several chats at the same time.

1. Once you've logged in to MSN Messenger, press ▲ or ▼ to highlight a buddy that is online.
2. Press the left soft key (▪▪▪) **Send**.
3. Enter the text of your conversation using the keypad, then press the left soft key (▪▪▪) **Send**.
4. If your buddy is online, they will hear a tone and a dialogue box appears in the display of their device.
5. When your buddy responds, you'll receive their response almost immediately.

End a chat session

1. While in a chat session, press the right soft key (▪▪▪) **Menu**. A pop-up menu appears in the display.
2. Press ▼ to highlight **End Chat**, and press OK. You're returned to the buddy screen.

Invite others to chat

If you're involved in more than one chat session at a time, you can invite people from other chat sessions to join you in a particular session.

1. While in the chat session in which you wish to invite others, press the right soft key (▪▪▪) **Menu.** A pop-up menu appears in the display.
2. Press ▼ to highlight **Invite**, then press OK. A list of users from other chats that you are involved in appear in the display.
3. Press ▼ or ▲ to move up or down the list to highlight the user you wish to invite.
4. Press the left soft key (▪▪▪) **Select** to invite the highlighted user to your chat session.

5. To invite multiple users, repeat steps 1 through 4 as many times as necessary.

View chat members

To view the list of members in a chat session:

1. While in a chat, press the right soft key ( ) **Menu**. A pop-up menu appears in the display.
2. Press ▼ to highlight **Chat Members**, then press OK. The buddy list of members involved in the chat session appear in the display.
3. Press the left soft key ( ) **Done** to return to the chat screen.

Block a contact

Once you block a contact, the blocked contact can't see you online. This works both ways; you can't send a message to a blocked contact, although you can see if they are online.

1. At the buddy screen, press the right soft key **Menu**.
2. Press ▼ until **Block** is highlighted, then press OK. You're returned to the buddy screen.

Unblock a contact

1. At the buddy screen, press the right soft key **Menu**.
2. Press ▼ until **Unblock** is highlighted, then press OK. You're returned to the buddy screen.

Sign out of MSN Messenger

1. At the buddy screen, press the right soft key ( ) **Menu**.
2. Press ▼ to highlight **Sign Out**, then press OK. You're returned to the MSN Messenger main screen.

My Text

My Text are short, pre-composed messages that can be used to initiate or respond to messages in a chat session. Sometimes called templates, **My text** can be especially useful if you're short on time.

1. At the chat screen, press the right soft key (...) **Menu**. **My Text** is highlighted.
2. Press OK. The following pre-composed text is available:

   1 Yes
   2 No
   3 Thanks.
   4 Please call me on my mobile.
   5 I'll be right there.
   6 I'm running late.
   7 :-)
   8 ;-)
   9 :-(

3. Press ▼ to highlight a message to insert into your chat session.
4. Once the desired message is highlighted, press the left soft key (...) **Insert**. You're returned to the chat screen with the selected text inserted into your message.
5. Press the left soft key (...) **Send** to send the message.

Edit My Text

The nine pre-composed messages that come with **My Text** can be modified to suit your needs.

1. While at the MSN Messenger main screen, press the right soft key (▪▪▪) **Menu**. A pop-up menu appears in the display.
2. Press ▼ to highlight **Options**, then press OK. **Passport Account** and **Edit My Text** appear in the display.
3. Press ▼ to highlight **Edit My Text**, then press OK. The list of **My Text** messages appears in the display.
4. Press ▲ or ▼ to move up or down the list until the desired **My Text** message is highlighted.
5. Press ⌫ to backspace and delete a character. Press and hold ⌫ to clear all of the characters in the message.
6. Enter your changes to the **My Text** message using the keypad.

Tip: To switch text entry mode (from T9 to 123, and so on), press and hold * until the mode icon in the upper right of the display changes to the desired entry mode (abc, 123, T9, etc).

7. Press the left soft key (▪▪▪) **Done** when finished or the right soft key (▪▪▪) **Cancel** to return to the previous menu.

Windows® Media™ Player 8 for Smartphone

Windows Media player lets you enjoy music and video in stereo, whether saved to your Smartphone, SD Card, or

streaming from the Internet. You can download files with your PC and then transfer them to your Smartphone, or download files directly to your Smartphone using wireless Internet services. Media files are stored in your **Local Content** folder.

Open a Media Player file

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then press ▼ until **Windows Media** is highlighted.
3. Press OK. Windows Media Player opens to the **Local Content** folder.
4. Press ▲ or ▼ to browse through the list of media files until the file you wish to open is highlighted.
5. Press the left soft key () **Play** to play the selected file.

Tip: You can also play MP3 files in Windows Media Player.

Media Player Controls

The following navigation keys perform the functions listed while Windows Media Player is playing a file.

OK Plays the selected media player file.

▶ Press and hold to fast forward to the end of a Windows Media Player file.

◀ Press and hold to return to the beginning of a Windows Media Player file.

▲ Press and hold to increase the volume of a Windows Media Player file (while the file is playing).

Press and hold ▼ to decrease the volume of a Windows Media Player file (while the file is playing).

Solitaire

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then press ▼ until **More... is** highlighted.
3. Press OK. The **Games** menu appears in the display.
4. Press OK. **Solitaire** is highlighted. Press OK to open **Solitaire**.

- Press the left soft key ( ) **Draw** to draw a new hand.

5. Press the right soft key ( ), then select **New Game** from the pop-up menu.

Smartphone games can be downloaded from the Internet and stored on your Smartphone or SD Card. Instructions from the game download site should inform you of the location (folder) to store the application on your Smartphone.

The Accessories menu

Calculator

The calculator allows you to perform general mathematical functions, such as addition, subtraction, multiplication, and division. You can use the calculator to perform basic calculations, store and retrieve values, and display the last series of calculations.

Use the Calculator

1. At the Home Screen, press the left soft key (▪▪▪) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then press ▼ until More... is highlighted.
3. Press OK. **Accessories** is highlighted.
4. Press OK. The following sub-menus appear in the display with **Calculator** highlighted.

   1 Calculator
   2 Infrared Receive
   3 Modem Link

5. Press OK. The **Calculator** screen appears in the display.
6. Enter the first number in your calculation, then press the right soft key (▪▪▪) **Options**. A pop-up menu appears in the display with the following options.

   Add
   Subtract
   Multiply
   Divide
   Decimal Point
   Equals

7. Press ▲ or ▼ to select the operand of your choice.
8. Enter the second number in the calculation, then press right soft key ( ) **Options**.
9. Press ▼ until **Equals** is highlighted, then press OK. The sum of your calculation appears in the display.

Wireless Link

Once you configure and activate the connectivity features for your Smartphone, the Wireless Link application appears on your PC desktop and allows you to transfer files from your desktop PC to your Smartphone. You can transfer files via USB, or even the infrared port if your PC is equipped with IR. Files are copied to the IPSM\My Documents folder on your Smartphone.

Infrared Receive

You can send files from a PC to your Smartphone via Infrared. Your Smartphone will prompt you prior to transmission of any files, at which time you'll have the opportunity to accept or cancel the file transfer.

If you have difficulty sending or receiving via IR:

- Transfer only one file at a time. No more than 25 contacts should be transferred at a time.
- Make sure that the IR port windows are clear and free of any dirt or obstacles.
- Some types of lighting may interfere with the transmission. Move to another room or dim the lighting.

Receive a File from your PC

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then press ▼ until More... is highlighted.
3. Press OK. **Accessories** is highlighted.
4. Press OK. The following sub-menus appear in the display with **Calculator** highlighted.

   1 Calculator
   2 Infrared Receive
   3 Modem Link
5. Press ▼ to highlight **Infrared Receive** and press OK.
6. Align the IR port of your Smartphone with that of your desktop PC or laptop. After a brief pause the infrared icon appears in the taskbar on your PC indicating that you're connected to your Smartphone via IR.

Note: You can hear tones on your PC speaker if the sound on your computer is enabled.

7. Double-click on the Infrared icon in the taskbar of your PC. The Wireless Link window appears in the display.

Note: The Wireless Link interface is much like Microsoft Explorer. Navigate to folders on your PC using a combination of drop down boxes and navigation icons.


Wireless Link
Select the files or folders you want to send to another wireless device and click Send.
You can also drag the files or folders to Wireless Link on the desktop.
Send Files
Look in: My Documents
My i600 files
File name:
Help
Properties
Send
Close

8. Locate the files on your PC that you'd like to transfer to your Smartphone using the Wireless Link user interface, then press **Send**.

- **Sending files** appears on PC display and your Smartphone prompts for confirmation.

9. On the Smartphone, press the left soft key ( ) **Yes** to accept the files or the right soft key ( ) **No** to cancel the file transfer.

Modem link

Important! ActiveSync may not function properly when Modem Link is enabled. Deactivate modem link before establishing an ActiveSync connection.

Your Smartphone can be used as a modem, thus allowing wireless access to the Internet and E-mail from your desktop PC. You can connect your computer to your Smartphone in this manner via infrared or USB.

Your Smartphone can only be used as a modem if you have purchased Mobile Office Suite from Verizon Wireless.

Set up Modem Link

Before you can experience the wireless connectivity of Modem Link, you'll need to configure the modem link connections port and baud rate.

1. At the Home Screen, press the left soft key ( ) **Programs**, then press ▼ until **More...** is highlighted.
2. Press OK, then press ▼ until More... is highlighted.
3. Press OK. **Accessories** is highlighted.
4. Press ▼ until **Modem Link** is highlighted.

5. Press OK. A message appears in the display regarding **ActiveSync** and **Modem Link**.
6. Press the left soft key ( ) **OK**.
7. The **Modem Link** properties in the following table appear in the display.

Setting	Function
Connection	Select the connection between your PC and Smartphone. Options are **Serial (COM1)**, **IrCOMM**, and **USB**
Baud Rate	Select the rate at which data is transferred between your Smartphone and PC. Options range from 110 to 256000 buad

8. Press ▼ until the setting that you wish to modify is highlighted.
9. Press ◀ or ▶ to change the properties for the highlighted setting.

Activate Modem Link

Once you've set up modem link's connection settings, you'll need to activate modem link.

1. While in Modem Link connection settings, press the right soft key ( ) **Menu**. **Activate** and **Deactivate** appear in the display, with **Activate** highlighted.
2. Press OK. Modem Link is activated.

Important! ActiveSync may not function properly when Modem Link is enabled. Deactivate modem link before establishing an ActiveSync connection.

Portable Keyboard (optional accessory)

The optional keyboard is similar to the keyboard for your PC, only smaller. The keyboard is useful with applications that may require extensive typing. However, you can also use the keyboard to shortcut to applications. A list of shortcut keys is included later in this section.

Attach the keyboard

1. Lay the keyboard on a flat surface near the Smartphone.
2. Plug the connector from the keyboard into the power/ accessory interface on the bottom end of the Smartphone. A tone sounds and a message appears in the display.
3. Press the left soft key ( ) **OK** to enable the keyboard, or press the right soft key ( ) **Cancel** to disable the keyboard.

Keyboard shortcuts

The following table contains a list of keyboard shortcuts to applications, menus, and sub menus on your Smartphone. Press the key or combination of keys listed in left column to perform the function listed in the right column.

Key(s)	Function
Menu	Return to the **Home Screen** from any menu.
	Launch **Internet Explorer**.
FN - 1	Open **Contacts**.
FN - 2	Open **Voice Notes**.
FN - 3	Open the **Calendar**.
FN - 4	Open **Tasks**.
FN - 5	Open the **Inbox**.
FN - 6	Open **MSN Messenger.**
FN - 9	Soft key 1
FN - 0	Soft key 2
FN - +/=	Turn the display on and off.
FN - E	End a call (if connected).
FN - T	Talk (or SEND).
FN -	Turn earpiece volume up.
FN -	Turn earpiece volume down.
FN -	End.

Safety and Warranty

Battery Precautions

Your Smartphone is powered by a rechargeable Li-ion standard battery. Please read the following precautions concerning the battery:

- Never use any charger or battery that is damaged in any way.
- Use the battery only for its intended purpose.
- If your Smartphone1
- has a strong signal, it uses less power; talk and standby time are greatly affected by the signal strength on the cellular network and the parameters set by the network operator.
- Battery charging time depends on the remaining battery charge and the type of battery and charger used. The battery can be charged and discharged hundreds of times, but it will gradually wear out. When the operation time, including talk time and standby time, is noticeably shorter than normal, it is time to purchase a new battery.
- If left unused, a fully charged battery will discharge itself over time.
- Use only Samsung-approved batteries and chargers. When a charger is not in use, disconnect it from the power source. Do not leave the battery connected to a charger for more than a 7 days, since overcharging may shorten its life.
- Extreme temperatures will affect the charging capacity of your battery. The battery may require cooling or warming before charging.

- Do not leave the battery in hot or cold places, such as in a car. It will reduce the capacity and life-time of the battery.
- Always try to keep the battery at room temperature. A phone with a hot or cold battery may not work correctly, even if the battery is fully charged. Lilon batteries are sensitive to temperatures below 0 °C (32 °F).
- Do not short-circuit the battery. Accidental short circuiting can occur when a metallic object (coin, clip, or pen) causes a direct connection between the positive and negative terminals of the battery.
- Dispose of used batteries in accordance with local regulations. Always recycle. Do not dispose of batteries in a fire.

Road Safety

Your wireless phone gives you the powerful ability to communicate by voice, almost anywhere, anytime. But an important responsibility accompanies the benefits of wireless phones, one that every user must uphold. When driving a car, driving is your first responsibility. When using your wireless phone behind the wheel of a car, practice good common sense and remember the following tips:

1. Get to know your wireless phone and its features, such as speed dial and redial. If available, these features help you to place your call without taking your attention off the road.
2. When available, use a hands-free device. If possible, add an extra layer of convenience and safety to your wireless phone with one of the many hands-free accessories available today.

3. Position your wireless phone within easy reach. Be able to access your wireless phone without removing your eyes from the road. If you get an incoming call at an inconvenient time, let your voice mail answer it for you.
4. Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow, ice and even heavy traffic can be hazardous.
5. Do not take notes or look up phone numbers while driving. Jotting down a To Do list or flipping through your phonebook takes your attention away from your primary responsibility, driving safely.
6. Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic. Try to plan calls when your car will be stationary. If you need to make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
7. Do not engage in stressful or emotional conversations that may be distracting. Make the people with whom you are talking aware that you are driving and suspend conversations that have the potential to divert your attention from the road.
8. Use your wireless phone to call for help. Dial the emergency number in the case of fire, traffic accident or medical emergencies. Remember, it is a free call on your wireless phone!
9. Use your wireless phone to help others in emergencies. If you see a car accident, crime in progress or other serious emergency where lives are in danger, call the

emergency number, as you would want others to do for you.

10. Call roadside assistance or a special non emergency wireless assistance number when necessary. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or any other special non-emergency wireless number.

Operating Environment

Remember to follow any special regulations in force in any area and always switch off your phone whenever it is forbidden to use it, or when it may cause interference or danger. When connecting the phone or any accessory to another device, read its user's guide for detailed safety instructions. Do not connect incompatible products. As with other mobile radio transmitting equipment, users are advised that for the satisfactory operation of the equipment and for the safety of personnel, it is recommended that the equipment should only be used in the normal operating position (held to your ear with the antenna pointing over your shoulder).

Electronic Devices

Most modern electronic equipment is shielded from radio frequency (RF) signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone. Consult the manufacturer to discuss alternatives.

Pacemakers

Pacemaker manufacturers recommend that a minimum distance of 15 cm (6 inches) be maintained between a

wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research and recommendations of Wireless Technology Research.

Persons with pacemakers:

- Should always keep the phone more than 15 cm (6 inches) from their pacemaker when the phone is switched on;
- Should not carry the phone in a breast pocket;
- Should use the ear opposite the pacemaker to minimize potential interference.

If you have any reason to suspect that interference is taking place, switch off your phone immediately.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may wish to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical devices, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information. Switch off your phone in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Switch off your phone in any facility where posted notices require you to do so.

Potentially Explosive Atmospheres

Switch off your phone when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Users are advised to switch off the phone while at a refueling point (service station). Users are reminded of the need to observe restrictions on the use of radio equipment in fuel depots (fuel storage and distribution areas), chemical plants or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often but not always clearly marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), areas where the air contains chemicals or particles, such as grain, dust or metal powders, and any other area where you would normally be advised to turn off your vehicle engine.

Emergency Calls

This phone, like any wireless phone, operates using radio signals, wireless and land line networks as well as user-programmed functions, which cannot guarantee connection

in all conditions. Therefore, you should never rely solely on any wireless phone for essential communications (medical emergencies, for example).

Remember, to make or receive any calls the phone must be switched on and in a service area with adequate signal strength. Emergency calls may not be possible on all wireless phone networks or when certain network services and/or phone features are in use. Check with local service providers. If certain features are in use (call barring, for example), you may first need to deactivate those features before you can make an emergency call. Consult this document and your local cellular service provider. When making an emergency call, remember to give all the necessary information as accurately as possible. Remember that your phone may be the only means of communication at the scene of an accident; do not cut off the call until given permission to do so.

Other Important Safety Information

- Only qualified personnel should service the phone or install the phone in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty applicable to the device.
- Check regularly that all wireless phone equipment in your vehicle is mounted and operating properly.
- Do not store or carry flammable liquids, gases or explosive materials in the same compartment as the phone, its parts or accessories.
- For vehicles equipped with an air bag, remember that an air bag inflates with great force. Do not place objects, including both installed or portable wireless equipment in the area over the air bag or in the air bag deployment

area. If wireless equipment is improperly installed and the air bag inflates, serious injury could result.

- Switch off your phone before boarding an aircraft. The use of wireless phones in aircraft may be dangerous to the operation of the aircraft, and is illegal.
- Failure to observe these instructions may lead to the suspension or denial of telephone services to the offender, or legal action, or both.

Care and Maintenance

Your phone is a product of superior design and craftsmanship and should be treated with care. The following suggestions will help you fulfill any warranty obligations and allow you to enjoy this product for many years.

- Keep the phone and all its parts and accessories out of the reach of small children's.
- Keep the phone dry. Precipitation, humidity and liquids contain minerals that will corrode electronic circuits.
- Do not use or store the phone in dusty, dirty areas, as its moving parts may be damaged.
- Do not store the phone in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the phone in cold areas. When the phone warms up to its normal operating temperature, moisture can form inside the phone, which may damage the phone's electronic circuit boards.
- Do not drop, knock or shake the phone. Rough handling can break internal circuit boards.
- Do not use harsh chemicals, cleaning solvents or strong detergents to clean the phone. Wipe it with a soft cloth slightly dampened in a mild soap-and water solution.

Warranty

STANDARD LIMITED WARRANTY

What is Covered and For How Long?

SAMSUNG TELECOMMUNICATIONS AMERICA, L.P. ("SAMSUNG") warrants to the original purchaser ("Purchaser") that SAMSUNG's Phones and accessories ("Products") are free from defects in material and workmanship under normal use and service for the period commencing upon the date of purchase and continuing for the following specified period of time after that date:

Smartphone	1 Year
Batteries	1 Year
Leather Case/Pouch	90 Days
Holster	90 Days
Other Smartphone Accessories	1 Year

What is Not Covered?

This Limited Warranty is conditioned upon proper use of Product by Purchaser. This Limited Warranty does not cover: (a) defects or damage resulting from accident, misuse, abuse, neglect, unusual physical, electrical or electromechanical stress, or modification of any part of Product, including antenna, or cosmetic damage; (b) equipment that has the serial number removed or made illegible; (c) any plastic surfaces or other externally exposed parts that are scratched or damaged due to normal use; (d) malfunctions resulting from the use of Product in conjunction with accessories, products, or ancillary/peripheral equipment

not furnished or approved by SAMSUNG; (e) defects or damage from improper testing, operation, maintenance, installation, or adjustment; (f) installation, maintenance, and service of Product, or (g) Product used or purchased outside the United States or Canada. This Limited Warranty covers batteries only if battery capacity falls below 80% of rated capacity or the battery leaks, and this Limited Warranty does not cover any battery if (i) the battery has been charged by a battery charger not specified or approved by SAMSUNG for charging the battery, (ii) any of the seals on the battery are broken or show evidence of tampering, or (iii) the battery has been used in equipment other than the SAMSUNG phone for which it is specified.

What are SAMSUNG's Obligations?

During the applicable warranty period, SAMSUNG will repair or replace, at SAMSUNG's sole option, without charge to Purchaser, any defective component part of Product. To obtain service under this Limited Warranty, Purchaser must return Product to an authorized phone service facility in an adequate container for shipping, accompanied by Purchaser's sales receipt or comparable substitute proof of sale showing the date of purchase, the serial number of Product and the sellers' name and address. To obtain assistance on where to deliver the Product, call Samsung Customer Care at 1-888-987-4357. Upon receipt, SAMSUNG will promptly repair or replace the defective Product. SAMSUNG may, at SAMSUNG's sole option, use rebuilt, reconditioned, or new parts or components when repairing any Product or replace Product with a rebuilt, reconditioned or new Product. Repaired/replaced leather cases, pouches and holsters will be warranted for a period of ninety (90) days. All other repaired/replaced Product will be warranted for a

period equal to the remainder of the original Limited Warranty on the original Product or for 90 days, whichever is longer. All replaced parts, components, boards and equipment shall become the property of SAMSUNG. If SAMSUNG determines that any Product is not covered by this Limited Warranty, Purchaser must pay all parts, shipping, and labor charges for the repair or return of such Product.

What Are the Limits On SAMSUNG's Liability? EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED HEREIN, PURCHASER TAKES THE PRODUCT "AS IS," AND SAMSUNG MAKES NO WARRANTY OR REPRESENTATION AND THERE ARE NO CONDITIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO:

·THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE;

·WARRANTIES OF TITLE OR NON-INFRINGEMENT;

·DESIGN, CONDITION, QUALITY, OR PERFORMANCE OF THE PRODUCT;

·THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR

·COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO.

NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN EXPRESS WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. ALL IMPLIED

WARRANTIES AND CONDITIONS THAT MAY ARISE BY OPERATION OF LAW, INCLUDING IF APPLICABLE THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY LIMITED TO THE SAME DURATION OF TIME AS THE EXPRESS WRITTEN WARRANTY STATED HEREIN. SOME STATES/PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE, USE, OR MISUSE OF, OR INABILITY TO USE THE PRODUCT OR ARISING DIRECTLY OR INDIRECTLY FROM THE USE OR LOSS OF USE OF THE PRODUCT OR FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL, CONSEQUENTIAL OR SIMILAR DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS, OR FOR DAMAGES ARISING FROM ANY TORT (INCLUDING NEGLIGENCE OR GROSS NEGLIGENCE) OR FAULT COMMITTED BY SAMSUNG, ITS AGENTS OR EMPLOYEES, OR FOR ANY BREACH OF CONTRACT OR FOR ANY CLAIM BROUGHT AGAINST PURCHASER BY ANY OTHER PARTY. SOME STATES/PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE/PROVINCE TO PROVINCE. THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF

THIS PRODUCT AND STATES PURCHASER'S EXCLUSIVE REMEDY. IF ANY PORTION OF THIS LIMITED WARRANTY IS HELD ILLEGAL OR UNENFORCEABLE BY REASON OF ANY LAW, SUCH PARTIAL ILLEGALITY OR UNENFORCEABILITY SHALL NOT AFFECT THE ENFORCEABILITY FOR THE REMAINDER OF THIS LIMITED WARRANTY WHICH PURCHASER ACKNOWLEDGES IS AND WILL ALWAYS BE CONSTRUED TO BE LIMITED BY ITS TERMS OR AS LIMITED AS THE LAW PERMITS.

THE PARTIES UNDERSTAND THAT THE PURCHASER MAY USE THIRD-PARTY SOFTWARE OR EQUIPMENT IN CONJUNCTION WITH THE PRODUCT. SAMSUNG MAKES NO WARRANTIES OR REPRESENTATIONS AND THERE ARE NO CONDITIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, AS TO THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE OR SUITABILITY OF ANY THIRD-PARTY SOFTWARE OR EQUIPMENT, WHETHER SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT IS INCLUDED WITH THE PRODUCT DISTRIBUTED BY SAMSUNG OR OTHERWISE, INCLUDING THE ABILITY TO INTEGRATE ANY SUCH SOFTWARE OR EQUIPMENT WITH THE PRODUCT. THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE AND SUITABILITY OF ANY SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT LIE SOLELY WITH THE PURCHASER AND THE DIRECT VENDOR, OWNER OR SUPPLIER OF SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT, AS THE CASE MAY BE.

This Limited Warranty allocates risk of Product failure between Purchaser and SAMSUNG, and SAMSUNG's

Product pricing reflects this allocation of risk and the limitations of liability contained in this Limited Warranty.

The agents, employees, distributors, and dealers of SAMSUNG are not authorized to make modifications to this Limited Warranty, or make additional warranties binding on SAMSUNG. Accordingly, additional statements such as dealer advertising or presentation, whether oral or written, do not constitute warranties by SAMSUNG and should not be relied upon.

Samsung Telecommunications America, L.P.
1130 East Arapaho Road
Richardson, Texas 75081
Phone: 1-800-SAMSUNG
Phone: 1-888-987-HELP (4357)

©2003 Samsung Telecommunications America. All rights reserved. No reproduction in whole or in part allowed without prior written approval. Specifications and availability subject to change without notice.

Index

A

About sub menu 25
Accessibility sub menu 26
Accessories menu 99
ActiveSync 44
- Accessing media files 47
- Browsing files 50
- Creating a partnership 58
- Creating media folders 47
- Installing 45
- Min PC requirements 44
- Options menu 46
- Upload files 47, 48
- Use via IR 49

Answer calls 15
Antenaa 6
Antenna picture 2
Appointments, creating 36
Area code 20
Auto answer 20

B

Back/Clear key 9
Battery charging 5
Battery installation 4
Battery removal 5
Buddies, adding 92

C

Calendar folder 51
Calendar menu 36
Calendar options 37
Calendar views 37
Call history 78
Call history icons 80
Call history, new contact ..80
Call options sub menu 20
Call waiting 82
Caller ID 82
Caller ID, blocking 82
Calls, place and receive ...14
Categories 41
Categories, assigning 41
Chat session
- Ending 93
- Inviting others 93
- Starting 92

Contacts
- Beam via IR 40
- Categories 41
- Create new 38
- Filtering 41
- folder 52
- Making calls from 40
- Viewing 40

Country code 20
Creating messages 64
Customer care, contact 13

D

Data connections 27
Date and time sub menu ..28
Display screen 7
Display specifications 1

E

Edit data connections 28
E-mail
- Description 66
- Incoming mail server 67
- Network options 67
- Options 67
- Outgoing mail server 67
- Server type, entering 67
- Setup 66

Enter
Numbers 62
Punctuation 60
Spaces 61
Symbols 60

F

Favorites
Adding 90
Adding folders 90

G

Games, solitaire 98

H

Home key 9
Home screen 6, 24
Hot keys 9, 10

I

i600 - Features 1
i600 features 1
i600 introduction 1
Icon
1X data protocol 8
Battery power level 8
Charging 8
GPS 8
Missed call 8
Receive and transmit 8
Ringer off 8
Ringer on 8
Roaming mode 8
Signal strength 8
SMS/E-mail message 8
Speakerphone mode 8
Icons, list of 8
Inbox folder 53
Infrared receive 100
Internet Explorer 88
Internet Explorer, launching 88
Internet key 11

J

Jpeg files, accessing 49

K

Key
Back/Clear 9
Home 9
Hot 9
Internet 11
Navigation/OK 9
Quick list 12
Soft 10
Voice memo 11
Voice Signal 11
Voicemail 13
Volume 11
Keyboard shortcuts 105
Keyboard, attaching 104
Keyboard, portable 104
Keypad 9
Keypad description 9
Keypad, alpha-numeric 9, 10

L

Language setting 31
Low battery indicator 4

M

Media folders, creating 47
Menu navigation 16
Message Types 63
Messaging 63
Microsoft ActiveSync 44
Modem link
Activate 103
Description 102

Setup 102
MSN Messenger 90
Multi-tap
Description 61
Modes 62
My text 95

N

Navigate, shortcuts 16
Navigating menus 16
Navigation key, uses 9
Navigation/OK key 9
New e-mail ring tone 21
Numbers, entering 62

O

One-touch dialing 43
Owner info sub menu 29

P

Partnerships 58
Partnerships, creating new 58
Phone # this phone 20
Phone settings sub menu .34
Pocket Internet Explorer ...88
Portable keyboard 104
Power management 30
Profile, edit 23
Profiles
Definition 22
Profiles sub menu 22
Programming speed dial ..42
Punctuation
Entering 60

Q

Quick list key 12

R

Regional settings
sub menu 31
Reminder ring tone 21
Remove programs
sub menu 32
Return to home screen 9
Ring tone, setting 21
Roaming 77

S

SD card 17
SD card capacity 17
SD card use 19
SD card, removal 19
SD card, transfer data 17
Security sub menu 33
Server type, entering 67
Settings menu 20
Shortcut navigation 16
Smartphone folders 51
SMS text messages 63
Soft keys 10
Solitaire 98
Sounds sub menu 21
Spaces, entering 61
Speakerphone, use in call 15
Speed dial 42
Speed dial, programming ..42
Speed dial, using 43
Sub menu
About 25
Accessibility 26
Calculator 99
Call options 20
Data connections 27
Date and time 28
Home screen 24
Owner information 29
Phone settings 34
Power management 30

Profiles 22
Regional settings 31
Remove programs 32
Security 33
Sounds 21
TTY 35
Symbols, entering 60

T

T9 59
Tasks 84
Tasks, activating 85
Tasks, creating new 84
Tasks, deleting 85
Tasks, marking complete . 84
Text message options 65
Text messages, creating .. 64
Text Messaging 63
Text, entering 59
Text, symbols, and numbers 59
Three-way calling 83
Tip
Entering symbols 91
Find a name 14
Message options 64
Message sending 64
Problems with e-mail 71
Quick list 12
SD slot uses 17
Setting time 29, 36
SMS messages 65
Speakerphone 15
Synchronization 50
Text entry 64, 65, 96
TTY enable 35
TTY sub menu 35
Two-touch dialing 43

U

Upload media files 48

V

Voice notes 86
Voice notes, recording 86
Voice notes, renaming 87
Voice Signal
Features 72
Voice signal 72
Description 72
Digit dial 72
Name dial 73
Name lookup 75
Open app 76
Quick dial 74
Settings 76
Train quick dial 74
Voice Signal key 11
Voicemail 63
Voicemail setup 13, 63
Voicemail, checking 63

W

Warranty 114
WAV files, accessing 49
Windows Media Player
Controls 97
Description 96
Opening files 97
Wireless link 100